

ascom *The world in your hands*
Ascom Eurit 33 / 33 plus

Operating Instructions

ISDN telephone




Safety tips

Note the following safety precautions for positioning, connecting and operating the telephone.

- ⇒ *Place your telephone on a non-slip mat!*
- ⇒ *Position the connection cable carefully to avoid accidents!*
- ⇒ *Avoid positioning the telephone near heat sources, in direct sunlight and in the vicinity of other electrical equipment.*
- ⇒ *Protect your telephone against dust and avoid exposing it to moisture, steam or aggressive liquids.*
- ⇒ *Plug the connection cable only into the outlet intended for this purpose.*
- ⇒ *Connect only authorised accessories.*
- ⇒ *Never*
 - *open your telephone yourself!*
 - *touch contacts with pointed, metallic objects!*
- ⇒ *Clean your telephone only with a slightly damp cloth or antistatic cloth. Never use a dry cloth or cleaning and chemical substances.*
- ⇒ *Do not use your telephone in damp rooms (e.g. bathroom) or in areas at risk from explosion.*

Operating elements and displays



Display: Signs and symbols

- | | | | |
|----|---------------------------------|---------|---------------------------|
| ∨ | Show next display | →☒☒ | Enter in phonebook |
| ∧ | Show previous display | ☒☒→ | Read from phonebook |
| ☒ | Inbox (calls, messages, mails) | ☒ | Reject |
| ☒ | Mail | ☒ | Call forwarding permanent |
| ☒→ | Send mail | ☒ | Call forwarding if busy |
| ☒ | Telephone answering machine TAM | ☒ | Call forwarding delayed |
| ☒ | Number suppressed | ☒ | Callback |
| ▶ | Play | ☒ | Hotline |
| ■ | Stop | ☒ | Call filter |
| | Pause | ☒ | Appointment |
| ⏪ | Previous message (skip) | ☒ | Loudspeaker |
| ⏪ | Display previous selection | ☒ | Microphone |
| ⏩ | Next message (skip) | ☒ | Microphone Mute |
| ⏩ | Display next selection | ☒ | Do Not Disturb |
| ↑ | Answer only | ☒ | Headset |
| ☒ | Answer and record | i | Information |
| ☒ | Provider | | |
| ☒☒ | Phonebook | ☒ ... E | User symbols |

Operating elements and displays

- 1 Display**
Two-line alphanumeric display with 24 characters per line
- 2 Foxkey (multifunction key)**
The available functions are shown under the display line and directly called up by pressing the Foxkey under the relevant text.
- 3 Menu key**
Press once: Select main menu, return from sub-menus to the main menu.
Press and hold down: Switch TAM on and off for all users
- 4 Telephone answering device LED**
Unlit: TAM switched off.
Lit: TAM switched on, no messages.
Slow flash: TAM switched on, no messages.
Fast flash: TAM memory full
- 5 User key**
Select user A, B, C, D or E
- 6 User LED**
Unlit: All users accept calls. Lit: At least one user is not accepting calls (Call Forwarding active, Do Not Disturb etc.)
- 7 Dialling keypad**
12 dual-function keys for numerical and alphanumeric entry
- 8 Short dialling keys**
The five short dialling keys are capable of storing two numbers and are freely programmable.
- 9 Emergency mode switch**
The emergency mode switch is located under the write-on label.
- 10 ESC key (Escape key)**
Press once: Skip to previous menu level. Press and hold down: Switch to standby mode
- 11 LOG key**
Shows the numbers of the last 10 answered calls
- 12 Redial key**
Shows the last 10 dialled numbers
- 13 Loudspeaker key**
Switch loudspeaker on and off
- 14 R key (enquiry key)**
Initiate enquiry call, switch between two calls
- 15 Park key**
Park and retrieve a call
- 16 Minus and plus keys (cursor keys)**
Move cursor left or right, adjust volume up or down, decrease or increase values

ascom Eurit 33 / 33 plus Euro-ISDN Telephone

In purchasing the Eurit 33 / 33 you have selected a Swiss-quality product.
Thank you for your confidence in our company.

The Eurit 33 / 33 is designed for connection to the public Euro-ISDN network.

If you plan to use the Eurit 33 / 33 plus in conjunction with a PBX, please refer to the Chapter »PBX Operation«.

Please read these operating instructions carefully to familiarise yourself with and take full advantage of the benefits of your new Eurit 33 / 33 plus.

Keep these operating instructions in a safe place!

Important information on your Euro-ISDN connection

These operating instructions describe all the functions you need to apply for from your network provider. Some of these functions are available at a charge.

The services available at your ISDN access port depend on the type of subscriber connection you have.

For further information on the available services, contact your network provider.

Contents

Safety tips	2
Operating elements and displays	3
Setting up the telephone	5
Contents of the package	5
Connecting the telephone	5
Display on setup	6
Positioning the telephone	6
Preparing the write-on labels	6
Setting up the telephone	7
Changing the housing	7
Emergency mode	7
Basic operating information	8
User concept	8
Changing users	8
Display in standby mode	9
Menus	10
Acoustic signals	10

Contents

Dialling	11
On-hook dialling	11
Redial	11
Dialling numbers from the caller list	12
Dialling from the call LOG	13
Dialling from the phonebook	14
Speed-dialling	14
Telephoning	15
Incoming calls	15
Rejecting incoming calls	15
Handsfree	15
Listening by loudspeaker	16
Mute	16
Phonebook	17
General information	17
New entry	19
Changing an entry	21
Deleting an entry	22
Advanced features	23
Call forwarding	23
Individual user charges, call charge total	24
Setting hotline (direct call)	25
Setting appointments (alarm function)	26
Enquiry call	26
Switching between calls	27
Call transfer	27
Three-party conference	28
Call divert (CD)	28
Automatic callback or redial if busy	29
Call waiting / accepting a second call	30
Park	31
Speed-dialling	32
Malicious Call Identification (MCID)	34
DTMF (Dual Tone Multifrequency)	34
Subaddresses	35
Send keypad	35
Send mail (UUS)	36
Info messages	37

Contents

Basic settings	38
User setup	38
Deleting users	39
Setting the date and time	40
Setting the language	41
Switching the headset on and off	42
Settings for automatic redial (autodial)	43
PBX settings	43
Setting the contrast	44
Setting the tax factor and currency	45
Editing the provider list / dialling via provider	46
User settings	48
Setting the ringing melody and volume	48
Switching the call filter on and off	49
CLIR (Calling Line Identification Restriction)	50
Call waiting	51
Entering the park code	52
Eurit 33 plus telephone answering machine (TAM)	53
Introduction	53
Activating/deactivating the TAM for all users	54
Activating / deactivating the TAM for individual users	54
Call acceptance	55
Greetings	56
Default greeting	56
Recording greetings	56
Selecting / playing back the greeting	58
Deleting / changing greetings	59
Incoming messages	60
Telephoning during recording of an incoming message	60
Message playback	60
Deleting messages	62
Ring count / economy function	63
Message length / listen	64
Recording quality / recording time	65
Recording the closing message	66
Eurit 33 plus remote access	67
Introduction	67
Setting the PIN-Code	68
Setting up a connection to the TAM	69

Contents

Remote access with economy function	69
Remote access functions	70
Setting room surveillance	73
Setting a direct access number	74
Setting the number of rings for automatic remote activation of the TAM	75
Recording a help message	76
PBX operation	77
Setting the Exchange Access Code (EAC)	77
Incoming EAC	78
Setting the transfer type	79
Call transfer on-hook	80
Keypad information	81
Sending the keypad automatically	82
Reset functions	83
Resetting the telephone to default	83
Deleting the phonebook	83
Deleting the remote access PIN	84
Resetting the TAM	84
Deleting the parameters	85
Important information	86
Show software version and checksum	86
PC dialling option (PC Dialer II)	86
Software update	86
Technical Data	87
Warranty conditions	87
Disposal	87
Default settings / delivery status	88
Menu structure	89
Index	91


Setting up the telephone

Contents of the package

- Eurit 33 / 33 plus with mounted housing
- Handset
- Telephone connection cable
- Spiral handset cord
- Transparent cover for write-on panel
- Operating Instructions

Connecting the telephone

The connection sockets are located on the underside of the telephone.



To release the cable use a ballpoint pen or similar object to press the holding hook on the connector in the direction of the connector body and prise the connector out along with the cable.

Setting up the telephone

Display on setup

Once you have connected your Eurit 33 / 33 plus the display shows the prompt: »Bitte geben Sie mindestens eine MSN (Mehrfachrufnummer) mit Bezeichnung ein«. (Please enter at least one MSN (Multiple Subscriber Number) with code).

To be able to use all the functions of your Eurit 33 / 33 plus, you must define at least one user (i.e. enter at least one Multiple Subscriber Number [MSN]).

The detailed procedure for setting a user is described under »User setup«

If you wish to use the telephone first and define a user later:



Dial: 0551234567_

Lift the handset and enter a number.
The number is displayed.



21.01.99 11:11
>>

Replace the handset when the call is over.
Date and time are displayed.

⚠ *Do not forget to define at least one user later, to ensure full functionality of your Eurit 33 (see »User setup«).*

Positioning the telephone

Your telephone is designed for use under normal conditions. Modern furniture is coated with a wide range of varnishes and plastics and treated with a variety of different finishes and polishes. Some of these agents may contain ingredients that corrode and soften the plastic pads of the telephone. If this happens, it may lead to undesirable marks on the furniture surface.

Understandably, the manufacturer cannot accept any liability for such damage.

We therefore recommend that you position your telephone on a non-slip mat, especially if it is placed on new or varnished furniture.

Preparing the write-on labels.

Turn over the printed write-on label for speed-dial numbers or cut out a label from the back of the operating instructions. The label for your own telephone number is also located at the back of the operating instructions.

If you already know which speed-dial numbers you wish to store, note the associated numbers or functions on the write-on label for speed-dial numbers. Enter your own number(s) and emergency numbers on the write-on label for your telephone number.

Place the labels in the label recesses (left of the short dialling keys or on the underside of the handset) and cover them with the transparent panel.

Setting up the telephone

Changing the housing

Your telephone is delivered with a standard mounted housing (upper housing cover). You can change the housing as required, in order to customise your telephone. Other housings in a range of colours are available from your telephone retail outlet as accessories for the Eurit 33 / 33 plus.

Unplug the telephone before changing housings! To change the housing, grip the upper left-hand corner (above the display) with the right hand. Place the left hand on the handset and press down against the base of the telephone. Now give the cover a good pull towards you (slight upward pull).


Position the new housing correctly and press it onto the telephone until it clicks into place. Check that all keys can be activated easily. Plug the telephone in again.

Emergency mode

If the 230 V power supply is cut off from the mains connector (NTBA), the ISDN port is powered directly from the exchange (emergency mode). This remote power supply is sufficient only to power a single telephone.

If several telephones are operated from the same connection, only one set may be authorised for emergency mode. Otherwise the entire ISDN port is disabled during emergency operation.

The emergency mode switch is located under the write-on label for one-touch numbers.



Activating emergency mode authorisation

Emergency mode authorisation can be activated by pressing the switch (e.g. with a ballpoint pen). The switch slides to the lower position.

Deactivating emergency mode authorisation

Slide the switch to off position by pressing against the retaining spring (e.g. with a ballpoint pen).

- ⇒ You can use an emergency-authorised set to telephone in the normal manner.
- ⇒ In the event of a power failure the settings and entries in the phonebook are retained.
- ⇒ During emergency mode the display may be switched off. Ringing and loudspeaker volume may also be reduced.
- ⇒ The emergency mode telephone signals calls for all Multiple Subscriber Numbers (MSN).
- ⇒ To telephone in emergency mode you must first lift the handset and then dial the number (loudspeaker key does not function).
- ⇒ The emergency mode telephone should be clearly marked with a stick-on label.

Basic operating information

User concept

The Eurit 33 / 33 plus allows you to set up to five users for one telephone. For example, if you use the telephone at home you can set the following users: »Mother«, »Father«, »Child 1«, »Child 2«, and »Child 3«. If, for instance, you use it for work and private applications, you can set »Company«, »Private«, »Club 1«, »Club 2«, and »Club 3«. You can switch from one user to another by pressing the user key. The display shows the active user's code (A, B, C, D or E).

➔ *The detailed procedure for setting different users is described in the Chapter »Basic settings«.*

Once you have defined the relevant settings for each user, your Eurit 33 / 33 plus handles various functions individually depending on the set user. For every call the active user's number is displayed on the partner's telephone. Incoming calls are assigned to the relevant user and stored in his own caller list or TAM. Costs are charged to the individual users. Calls can be separately forwarded according to the user's individual requirements.


Changing users

If a user code (A, B, C, D or E) is displayed on the right of the upper display line, the user can be changed as follows:




21.01.99 11:11 A >>

The active user is displayed on the right of the upper display line.



.....Tom.....

Press the user key.
The name of the next user is briefly displayed.



.....John.....

Press the user key until the relevant user is displayed.



21.01.99 11:11 E >>

After a brief pause the previous display re-appears, with the code of the selected user in the upper display line.

Basic operating information

Display in standby mode











If your Eurit 33 / 33 plus is in standby mode, the display shows the date, status pictograms (if applicable), the time and the active user code. If more than 8 status pictograms are displayed, the date is not shown.





Standby mode for fewer than 8 status pictograms.



Standby mode for more than 8 status pictograms. The status pictograms are always displayed right-justified in the following order: The meanings are as follows:

-  Hotline on
-  TAM on
-  Not Disturb
-  Number suppressed
-  Filter on
-  Provider on
-  Appointment on
-  Call forward on (any user)
-  Callback on
-  Headset on




If you press the Foxkey under >> you are given the choice of the functions »Suppress No.« or »TEll No.« and can activate them by pressing the Foxkey again. The associated status pictogram is displayed or disappears.

Basic operating information


Menus

The Eurit 33 / 33 plus offers simple operation thanks to menu-driven guidance. Entries in the phonebook (and subsequent editing), settings and programming are performed using menus. If you have selected menus or submenus, the handset must always be on-hook. If you receive a call or lift the handset during menu selection, the procedure is automatically aborted.


Use the menu key and Foxkey to select menus or submenus as follows:



Hold down the ESC key until the Eurit 33 / 33 plus is in standby mode (date, status and time displayed).




Press the menu key until the relevant menu is shown. »Phonebook«, »Functions«, »Settings«, »Installation«.
After the last menu the telephone returns to standby mode.



Press the Foxkey under \vee or \wedge until the desired submenu is displayed.
Execute the function.



Press the menu key to go to the next-highest menu level.



Press the ESC key to return to standby mode.

↪ *The entire menu structure is described under »Important information«.*

Acoustic signals

Your telephone offers further operating assistance by means of acoustic signals:

Confirmation signal

This confirms correct entries/changes by emitting two short, high tones.

Warning signal

This alerts you to incorrect manoeuvres or entries by emitting a single deep warning signal.

On-hook dialling



```
Dial: 0551234567_  
00→ *00 del >>
```

Enter the number you wish to call.
You can press the Foxkey under 00→ to search for and dial a number stored in the phonebook (see »Dialling from the phonebook«)
Press the Foxkey under *00 to enter the dialled number in the phonebook.
Press the Foxkey under »del« to delete the character at the cursor position.



```
0 0551234567_  
terminate A
```

Press loudspeaker key.



```
0 0551234567 A  
DM 0.10 terminate >
```

Lift the handset when your call has been answered.

Redial

The redial memory stores the 10 last-dialled telephone numbers irrespective of which user has entered the numbers (the redial memory is not user-specific). You can call these numbers again without entering the numbers.



```
Newman John A  
del *00 i ^ v
```

Press the redial key, if necessary several times, to select a number from the last-dialled number list.
The display shows the last-dialled number or, if this is stored in the phonebook, the associated name.



```
0551234567 A  
del *00 i ^ v
```

You can scroll up or down the list using the Foxkey under v or ^ .



```
0 0551234567 A  
terminate
```

Lift the handset or press the loudspeaker key.
The number is dialled.


- ⇒ If the redial memory is full, the oldest entry is overwritten.
- ⇒ To delete an entry in the redial memory, press the Foxkey under »del«.
- ⇒ To display detailed information on an entry in the redial memory, press the Foxkey under »i«. The display shows the active user, charge and duration of the call.
- ⇒ Calling Line Identification Restriction (CLIR, suppress calling number) is recognised by the redial memory and indicated by a »C« in front of the number.

Dialling


Dialling numbers from the caller list

Every unanswered call is entered in an individual caller list for each user. Up to 30 calls are stored in the caller list (in total for all users).

If someone has tried to reach you, a message - for example »3(5)« - appears in the lower display line. The number in brackets indicates that 5 calls have been made to your Eurit 33 and the number preceding this indicates that 3 calls were intended for the active user.




11.11.98 11:11
»3(5)«



0551234567
del i


Press the Foxkey under »3(5)« to call up your personal caller list.

The display shows the number of the most recent incoming call or, if this is stored in the phonebook, the caller's name.



Newman John
del No. i

If several calls have been made to your telephone, you can scroll up or down the list using the Foxkey under ^ or v .



Newman John
terminate

Lift the handset or press the loudspeaker key. The number is dialled.

- Press the Foxkey under »i« to display the date and time of the call (if a caller has called several times e.g. 3x, the date and time of the last call are displayed).
- After 30 calls the oldest entry is overwritten.
- Once you have returned the call from the caller list, the unanswered call is deleted and stored in the redial memory.
- Press the Foxkey under »00« to enter the dialled number in the phonebook.
- To delete an entry from the caller list, press the Foxkey under »del« (the entry can only be deleted if no message has been left).
- If the caller has recorded a message, the lower display line also shows »i«. The message can be played back by pressing the Foxkey under »i«.
- If the caller has left a mail (UUS), the lower display also shows ». To show the mail, press the Foxkey under ».

Dialling from the call LOG

Your Eurit 33 / 33 plus stores the last 10 answered calls (total for all users) in the call LOG.



0551234567	C
del →00 i ^ v	

Newman John	C
del No. i ^ v	



0551234567	C
del →00 i ^ v	



0551234567	C
terminate	

Press the LOG key, if necessary several times, to select a number from the list of answered calls. The display shows the number of the most recently answered call or, if this is stored in the phonebook, the caller's name.

If several calls have been made to your telephone, you can scroll up or down the list using the Foxkey under \vee or \wedge .

Lift the handset or press the loudspeaker key. The number is dialled.

- Press the Foxkey under »i« to display the user along with date and time of the last answered calls.
- Press the Foxkey under →00 to enter the dialled number in the phonebook.
- To delete an entry in the caller list, press the Foxkey under »del«.

Dialling

Dialling from the phonebook



Phonebook
new ^ v

Press menu key
»Phonebook« appears in the display.



Ansel Tim
change new del ^ v

Press Foxkey under v ou ^.
The first or last entry in the phonebook is displayed.

To dial a number from the phonebook you have two options:

Either enter the first letters ...

For example, for the name »Newman«, press Key 6 twice.
The display shows the first name beginning with »N«.

Press the Foxkey under v until the name you are seeking is shown.

Lift the handset or press the loudspeaker key.
The number is dialled.

... or scroll

Press the Foxkey under v ou ^ to scroll through the phonebook.

Once the name you are seeking appears in the display, lift the handset or press the loudspeaker key. The number is dialled.



Nail Nancy
change new del ^ v



Newman John
change new del ^ v



Newman John
terminate



Bang Nancy
change new ^ v



Newman John
terminate

⇒ For detailed information on the phonebook (entering, editing, etc.), refer to »Phonebook«.

Speed-dialling



Dial: 0551234567
00→ +00 del >>

Press the relevant speed-dialling key briefly (numbers 1 to 5) or twice in rapid succession (numbers 6 to 10).

The preprogrammed number or function is displayed.



0551234567
terminate

Lift the handset or press the loudspeaker key.
The number is dialled or the function executed.


⇒ For detailed information on speed-dialling, refer to »Speed-dialling«.

Incoming calls

Incoming calls are signalled by the user's own set ringing melody, in order to acoustically distinguish between calls for different users.


The display shows the caller's number provided Calling Line Identification Presentation is active or the number is available. If the number is stored in the phonebook, the name is automatically displayed. The name on the left of the display shows which user is being calls.

Rejecting incoming calls




0551234567 A
John accept >>

If you do not wish to answer an incoming call:



0551234567 A
→TAM reject >>

Press the Foxkey under >> until »reject« appears in the lower display line.



21.01.99 13:55 A
1<1> >>

Press Foxkey under »reject«.
The call is rejected and the caller's number is stored in the caller list.

⇒ The lower display line offers you further options:

- →TAM (Forward call to TAM)
- forward (Forward call to another number, see »Advanced features«).

Handsfree

If you wish to conduct a call without using the handset, you can talk into the microphone of your Eurit 33 / 33 plus and listen to your call partner over the loudspeaker.



During the call press the loudspeaker key and hold down until you have replaced the handset.

You can hear your call partner in the handset as well as through the loudspeaker.



Replace the handset and release the loudspeaker key.
Handsfree operation is activated.



If you wish to continue the call on the handset, lift the handset.

Telephoning

Setting the volume during a call

The volume is set to medium. During a call you can adjust the volume (1 to 7).



During a call press the plus key (up) or minus key (down) to change the volume in the handset and loudspeaker. The setting is saved.

➤ *The volume can be set individually for each user.*

Listening by loudspeaker

Other people can listen to your call over the loudspeaker. The microphone is switched off.



☎ Newman John
DM 0.40 terminate >>

During the call press the loudspeaker key. You can hear your call partner in the handset as well as through the loudspeaker.



☎ Newman John
Mic off Keypad >>

Press the Foxkey under >>. The lower display line shows the new dialling options.



☎ Newman John
Mic on Keypad >>

Press Foxkey under »Mic off«. The microphone is switched off. The symbol in the display changes from ☎ to ☎.

Mute

If you do not wish your call partner to hear you (e.g. to speak to someone else in the room), you can switch the handset microphone off.



☎ 0551234567
Mic off Keypad >>

During the call press the Foxkey under >>. The lower display line shows the new dialling options.



☎ 0551234567
Mic on Keypad >>

Press Foxkey under »Mic off«. The handset microphone is muted. The symbol in the display changes from ☎ to ☎. To switch the handset microphone on again, press the Foxkey under »Mic on« (the symbol ☎ reappears).

Phonebook











To make calls quickly and simply, you can enter at least 100 names and numbers in a phonebook. The phonebook is accessible to all users.

General information

Letters are printed above the numbers on your keypad. To enter a letter, press the relevant key once or more until the letter appears. (For example, to enter »S«, press key 7 four times.

By pressing the Foxkey under »Ħ →« or »→ Ħ« you can switch between upper and lower case.

In addition to the alphabet, individual keys also provide special characters and accents.

- under  ? ! , ; ' "
- under  Ā Ä Å Æ Ç à á â ã ä å æ ç
- under  É è é ê ë
- under  ì í î ï
- under  Ñ Ö Ø ñ ò ó ô õ ö ø
- under  Ü ù ú û
- under  ÿ
- under  +
- under  / () < = > % & @ \$ C
- under  _ (space)

↗ *The character set may differ depending on the country and software version.*



To correct errors, use the arrow key to position the cursor at the character to be changed. Delete the character by pressing the Foxkey under »del«. At the end of a line you can use the plus key to enter a space.

Phonebook

If long numbers/names are entered, ... is displayed as the first character when the line is wrapped. The start is shown again once entry is completed.

Press the Foxkey repeatedly under \vee or \wedge to scroll through the phonebook.

Entering attributes

Attributes contain additional information (specific character sequences) on a number in the phonebook. They are used by your Eurit 33 / 33 plus to control functions e.g. activate Calling Line Identification Restriction (CLIR). In most cases the attributes must be entered before the number, but in certain cases the attribute needs to be added after the number. Note the following rules:

No. : P10551234567_
ok Attribute del

Provider: Select attribute »Provider« (P) as the first character, enter provider number (1, 2, 3, 4, 5 or 6), enter number.

No. : 1234Z9999_
ok Attribute del

Subaddress: Enter first part of the number, select attribute »Subadress« (Z), enter subaddress.

No. : X118_
ok Attribute del

Exchange access code: Select attribute »EAC« (X) as the first character, enter number.

No. : K*21#_
ok Attribute del

Keypad: Select attribute »Keypad« (K) as the first character, keypad number.

No. : C0551234567_
ok Attribute del

Calling Line Identification Restriction (CLIR)
Select attribute »Suppress No.« (X) as the first character, enter number.

PBX Operation

The following applies when using in conjunction with a PBX:

- Always enter a number in the phonebook along with the prefix, in order to display the name.
- Do not enter the exchange access code (EAC) if this is automatically inserted (see »PBX Operation: setting the EAC«).
- To allow your Eurit 33 / 33 plus to identify numbers for which no prefix has been given (e.g. emergency numbers, provider code) as external numbers, you must select the attribute »EAC« (Exchange Access Code). An »X« is then displayed in front of the number.

Phonebook

New entry

To make a new entry in your phonebook, proceed as follows:



```
Phonebook
new
```

Press menu key
»Phonebook« appears in the display.



```
Name: _
ok A→a
```

Press the Foxkey under »new«.



```
Name: Newman John_
ok a→A del
```

Enter the name. All available characters are permitted (see »General information«).



```
No.: _
ok Attribute
```

Press the Foxkey under »ok«.



```
No.: 1234_
ok Attribute del
```

Enter the associated number (if you first need to enter an attribute e.g. provider or keypad, proceed as follows).



```
No.: 1234_
back Provider >>
```

If you need to enter an attribute (provider, subaddress, EAC, keypad or CLIR) with the number, press the Foxkey under »Attribute« at the appropriate place.
The attributes are shown in the lower display line. Attribute entry can be aborted by pressing »back«.



```
No.: 1234_
Subaddress EAC >>
```

Press the Foxkey to show the relevant attribute under >> if this is not already displayed.



```
No.: 1234Z_
ok Attribute del
```

Press the Foxkey under the appropriate attribute symbol.

The attribute is inserted.

- »P« for Provider
- »Z« for Subaddress
- »X« for Exchange Access Code (EAC)
- »K« for Keypad
- »C« for CLIR



```
No.: 1234Z9999_
ok Attribute del
```

If necessary, enter additional information on the attribute (e.g. provider number, subaddress or keypad).

Phonebook



```
Reaction: none
ok << >>
```

Press the Foxkey under »ok«.
The display shows the response given when this number calls.



```
Reaction: no filter
ok << >>
```

Press the Foxkey under >> or << until the desired reaction is displayed.

Possible responses are:

- None
- No filter (calls from this number are also signalled if call filter is active)
- Busy (calls from this number are always rejected with Busy)
- on TAM (calls from this number are always forwarded to the answering device)



```
# Newman John
change new del ^ v
```

Press the Foxkey under »ok«.

The new entry is shown in the display. Once a reaction is set, the relevant symbol is shown in front of the name (# no filter, ¢ busy, ◻ TAM).

⇒ If the phonebook memory is full, the »Phonebook« display no longer shows »New«.

You can enter any number shown on the display (from redial list, caller list, call log or a manually dialled number) in the phonebook as follows:

```
0551234567
del #00 i ^ v
```

Press the Foxkey under #00.



```
Name: _
ok A↵
```

Enter the name.



```
Name: Sutter Klara_
ok A↵ del
```



```
No.: 0551234567
ok Attribute del
```

Press the Foxkey under »ok«.

The number is displayed. If an attribute is to be inserted in the number, use the arrow key to position the cursor and Press the Foxkey under »Attribute«. Set the attribute and reaction as described in the previous section.





```
Sutter Klara
change new del ^ v
```



Press the Foxkey under »ok«.


The new entry is displayed. La nouvelle entrée est affichée.


Changing an entry


 Phonebook
new ^ v


 Newman John
change new del ^ v


  Nail Nancy
change new del ^ v


 Newman John
change new del ^ v

 Newman John
change new del ^ v

 Name: Newman John
ok A→a del

 No.: 0551234567
ok Attribute del

 No.: 0551234567
back Provider >>

 No.: 0551234567
ok Attribute del

Press menu key

»Phonebook« appears in the display.

Press the Foxkey under \vee or \wedge .

The first or last entry in the phonebook is displayed.

To search the phonebook, you have two options:

Either enter the first letters ...

For example, for the name »Newman«, press Key 6 twice. The display shows the first name beginning with »N«.

Press the Foxkey under \vee until the name you are seeking is shown.

... or scroll

Press the Foxkey under \vee or \wedge until the name you are seeking is shown.

Press the Foxkey under »change«.

The name to be changed is displayed. Change the name as required.

Press the Foxkey under »ok«.

The number to be changed is displayed. Change the number as required.

If an attribute is to be inserted in the number, use the arrow keys to position the cursor and Press the Foxkey under »Attribute«. The attributes are shown in the lower display line (press the Foxkey under \gg to display additional attributes).

Press the Foxkey under the appropriate attribute symbol.

The attribute is inserted.

- »P« for Provider
- »Z« for Subaddress
- »X« for Exchange Access Code (EAC)
- »K« for Keypad
- »C« for CLIR

Correct use of the attributes is explained under »General information«.

Phonebook



```
No.: P20551234567
ok Attribute del
```

If necessary, enter additional information on the attribute (e.g. provider number, subaddress or keypad).



```
Reaction: none
ok << >>
```

Press the Foxkey under »ok«.

The display shows the reaction when a caller on this number calls.



```
Reaction: on TAM
ok << >>
```

Press the Foxkey under >> or << until the desired reaction is displayed.

Possible reactions are:

- None
- No filter (call from this number is also signalled if call filter is active)
- Busy (call from this number is always rejected with Busy)
- on TAM (calls from this number are always forwarded to the answering device)



```
☐ Newman John      A
change new del ^ v
```

Press the Foxkey under »ok«.

The change is completed. Once a response is set, the relevant symbol is shown in front of the name (☐ no filter, ☑ busy, ☐ TAM)

Deleting an entry

Entries in the phonebook are deleted by pressing the Foxkey under »del«.



```
Phonebook
new      ^ v
```

Press the menu key

»Phonebook« appears in the display.



```
Ansel Tim
change new del ^ v
```

Press the Foxkey under v or ^.

The first or last entry in the phonebook is displayed.

```
Newman John
change new del ^ v
```

Search the phonebook for the entry to be deleted (see under »Changing an entry«).



```
.....deleted.....
```

Press the Foxkey under »del«.

The entry is deleted. An acknowledgement is shown, followed by the next entry.

⇒ For safety reasons you can only delete entries individually. To delete the entire phonebook, refer to the Chapter entitled "Reset functions".


Advanced features

Call forwarding


Call forwarding can only be activated if at least one user is programmed for this function! Every user can program three options for forwarding to any number:

- Permanent call forwarding Incoming calls are forwarded immediately.
- Call forwarding on busy Calls are forwarded if the user is busy.
- Delayed call forwarding Incoming calls are forwarded after 5 rings.

To program the desired option (several are possible):




Press menu key until »Functions« is displayed.



Press the Foxkey under ∇ .


»Call FWD:«, appears followed by »off« or the symbols indicating forwarding options already programmed.

\rightarrow (permanent), \rightarrow (busy), \rightarrow (Delay).




Press the Foxkey under »Change«.

The display shows »Call FWD A, B, C, D or E:« (Symbol of active user). The symbols of forwarding options already programmed are then displayed. The lower display line shows the new forwarding options.




Press the Foxkey under »permanent«, »busy« or »Delay«

When deactivated, the corresponding symbol disappears from the upper display line. When activated, a space is displayed for entry of the destination number.



Enter the destination number.

By pressing the Foxkey under »del« you can delete digits at the cursor position. You can press the Foxkey under \rightarrow search for and dial a number stored in the phonebook (see »Dialling from the phonebook«)



Press the Foxkey under »ok«.

The display shows the symbols corresponding to the programmed call forwarding options. Repeat the procedure to define additional forwarding options and destination numbers.

Advanced features



Call FWD:
change ^ v

Press the Foxkey under »ok«.
The display again shows »Call FWD:« followed by the symbols corresponding to all programmed forwarding options.

- The telephone is delivered with all forwarding options deactivated.
- Destination numbers remain in memory even after a forwarding option is deactivated.
- You can also forward calls using speed-dial numbers (see Chapter on »Speed-dialling«).
- When using in conjunction with a PBX, please refer to the relevant chapter in the PBX manual.
- Following a power failure or after you have unplugged the Eurit 33 / 33 plus and plugged it in again, the forwarding status is displayed only after you have lifted and replaced the handset.

Individual user charges, call charge total

You can display and delete the taxes (charges) incurred by each user individually.
You can also call up the charge total for all calls made from the telephone.



Functions ^ v

Press menu key until »Functions« is displayed



Taxes: DM 99.50
change ^ v

Press the Foxkey under until »Taxes:« is shown. The currency indication (max. 4 characters) corresponds to the basic tax factor setting.



John: DM 99.50
ok del

Press the Foxkey under »change«.
The display shows the taxes for activated users.
Press the Foxkey under »del« to reset the charge total to zero.



Total: DM 201.40
ok

Press the Foxkey under »ok«.
The display shows the call charge total for the telephone.



Taxes: DM 99.50
change ^ v

Press the Foxkey under »ok«.
The display again shows »Taxes:«.

- You cannot delete the call charge total. Instead, you must delete the taxes for each user in order to reset the total to zero.
- Make sure you have set the correct tax factor.
You can define the national currency (in the upper display DM) yourself (see »Basic settings, setting the tax factor and currency«).

Advanced features

- Note that for technical reasons the displayed taxes may differ from the amount billed. The amount indicated on your telephone bill is binding.
- If you are using a provider, tax information may not be available. In this case your Eurit 33 cannot display taxes.
- Press the user key to switch users (if the user symbol is displayed in the upper line), in order to compare taxes incurred by different users.

Setting hotline (direct call)

You can set a hotline (direct call) on your Eurit 33 / 33 plus. If this function is set and the handset is lifted, the telephone automatically dials the programmed direct call number when any key is pressed.



Functions ^ v

Press menu key until »Functions« is displayed



Hotline: off
change ^ v

Press the Foxkey under v until »Hotline:« is shown. The current setting is displayed.



Hotline: off _
ok on 00→

Press the Foxkey under »Change«.
The direct call number can now be changed or entered.



Hotline:off ...1234567_
ok on 00→ del

Enter the hotline number. By pressing the Foxkey under »del« you can delete digits at the cursor position. You can press the Foxkey under 00→ to search for and dial a number stored in the phonebook (see »Dialling from the phonebook«). If the number is longer than the available space, it is shown in »abbreviated« form (...appears before the number).



Hotline:on ...1234567_
ok on 00→ del

Press the Foxkey under »on« or »off«.
The new setting is displayed.



Hotline: on
change ^ v

Press the Foxkey under »ok«.
Hotline is activated/deactivated.

Advanced features

Setting appointments (alarm function)

You can set up to 5 appointments (1 appointment per user). Possible settings are: Once-only appointment or daily appointment at a specific time.



Functions ^ v

Press menu key until »Functions« is displayed



Alarm: off change ^ v

Press the Foxkey under v until »Alarm« is shown. The current setting is displayed.



Interval: off ok Daily once

Press the Foxkey under »Change«.
»Interval« appears in the display. The current interval settings are then displayed (off, daily or once). The lower display line shows the options.



Interval: Daily ok off once

Press the Foxkey under »once« or »Daily«, to set an appointment or under »off« to deactivate a programmed appointment.



Time: 11:15 ok

Press the Foxkey under »ok«.
Once you have deactivated an appointment, the display again shows »Alarm«. When activated, a space is displayed for entry of the appointment.



Time: 17:10 ok

Change the appointment time or enter a new time (if no appointment is set, the current time is shown).



Interval: 17:10 Daily Alarm change ^ v

Press the Foxkey under »ok«.
The display again shows »Alarm«.

Enquiry call

This function is used if you are talking to a call partner and wish to consult another call party briefly without disconnecting the current call.



Press R key.
The dialling tone is heard (the first connection is put on hold).



Dial the number and talk to the second party.



Press R key.
You can now continue your first call.

Advanced features

Switching between calls

You have initiated an enquiry call and now wish to switch alternately between the two parties.



Press R key.
You are connected to the first call partner.



Press R key again.
You are connected to the second call partner.

- *When switching between calls, the number of the active call partner is displayed.*
- *To terminate one of the active connections, press the Foxkey under »terminate«.*

Call transfer

You have two active connections and wish to connect both call partners with each other (call transfer).



```
Newman John      A
transfer terminate >>
```

Press the Foxkey under >> until »transfer« appears in the lower display line.



```
Dial: -          A
☐☐→
```

Press the Foxkey under »transfer«.
Your call partners are connected with each other. If the handset is off-hook, the dialling display is shown. For handsfree operation the Eurit 33 / 33 plus switches to the basic display.

```
11.11.98        11:11 A
>>
```

- *If you are connected to a PBX and have set »Transfer on-hook«, you can also transfer two active connections by replacing the handset (see »PBX Operation«).*
- *You can also transfer calls using speed-dial numbers (see Chapter on »Speed-dialling«).*
- *If a call comes in during a call transfer operation, it is signalled once you have transferred the current call and replaced the handset (the new incoming call is not lost).*

Advanced features

Three-party conference

You are engaged in two calls and wish to talk to both partners simultaneously.



```
Newman John      A
Conference Keypad >>
```

Press the Foxkey under >> until »Conference« appears in the lower display line.



```
Conference
terminate >>
```

Press the Foxkey under »Conference«. You are now connected to both parties in a 3-way conference.



```
Newman John      A
transfer terminate >>
```

Press the Foxkey under »terminate«. You are connected with the last active call partner and can continue to switch between calls.

- If you are connected to a PBX, please refer to the relevant chapter in your PBX manual.
- You can also activate calls using speed-dial numbers (see Chapter on »Speed-dialling«).

Call divert (CD)

If you wish to forward an incoming call directly to another telephone number:

```
0551234567      A
John accept >>
```

Press the Foxkey under >> until »forward« appears in the lower display line.



```
0551234567      A
forward >>
```

Press the Foxkey under »forward«.



```
No.: _
ok 00➔
```

Enter the number to which the call is to be forwarded. You can press the Foxkey under 00➔ to search for and dial a number stored in the phonebook (see »Dialling from the phonebook«)



```
No.: 0557654321_
ok 00➔ del
```

Press the Foxkey under »OK«. The call is forwarded. An acknowledgement appears.



```
.....activated.....
```

Automatic callback or redial if busy

If the person you are calling is busy, you can activate automatic callback or automatic redial.

If automatic callback is active, a connection is set up automatically as soon as the person is free (i.e. has replaced the handset). Up to 10 automatic callbacks can be activated for all users.

If you have activated automatic redial, the number is redialled after an interval (programmable between 5 and 240 seconds). The number of redials can be set between 1 and 99 (see »Basic settings«).

```
Subscriber busy  A
Callback Autodial >>
```

If, during the 10 seconds that the adjacent message is shown, you press any key or do not select any of the services in the lower display line, the standby display reappears.

Automatic callback

Press the Foxkey under »Callback« if you wish to set up a connection automatically after the called party has terminated the current call. Automatic callback is activated. An acknowledgement appears.

The activated callback is indicated by the corresponding status pictogram in the display. As soon as the called party has replaced the handset, his telephone rings.

Redial

Press the Foxkey under »Autodial« if you wish to activate automatic redial (see »Basic settings«). Automatic redial is activated. An acknowledgement appears.

The display shows the remaining dial attempts and the time until the next dial attempt.



```
.....activated.....
```

```
27.02.99    13:44 A
>>
```



```
.....activated.....
```

```
Autodial : 10x    0 '60"
terminate        >>
```










- *If you no longer wish to answer the callback, leave your handset on-hook and press the Foxkey under »Reject«.*
- *A callback remains active for 40 minutes. After this it is automatically cancelled by the exchange.*
- *This function must be supported by your network provider.*

Advanced features

- You can deactivate a callback by pressing the Foxkey under >> until »Callback« appears in the lower display line. Press the Foxkey again under »Callback« to show a list of all set callbacks. Press the Foxkey under »del« to delete the set callback displayed.
- If you are connected to a PBX, please refer to the relevant chapter in your PBX manual.

Call waiting / accepting a second call

If another call comes in during an active call, the second call is signalled by the call waiting tone. The display also shows the number and name (if stored in the phonebook). You have the following options:



The lower display line shows you that the call is for user Urs.

Either answer the call ...

Press the Foxkey under »Accept«.

... or reject it.

Press the Foxkey under >> until »Reject« is shown.

Press the Foxkey under »Reject«.

The number or name of the original caller is shown.

... or forward the call to your TAM.

Press the Foxkey under >> until »→TAM« appears in the lower display line.

Press the Foxkey under →TAM.

The telephone answering device answers the call.

... or forward the call to another number.

Press the Foxkey under >> until »Forward« appears in the lower display line.

Press the Foxkey under »Forward«.

Enter the number to which the call is to be forwarded. You can press the Foxkey under @@→ to search for and dial a number stored in the phonebook (see »Dialling from the phonebook«).

Advanced features



```
.....accept.....
```

```
Newman John      A  
DM 0.50 terminate
```

Press the Foxkey under »OK«.
The call is forwarded. An acknowledgement appears.

- To remain undisturbed during an active call, you can deactivate the »Call waiting« function (see »Call waiting«).

Park

You can park a call and retrieve it on another telephone within 3 minutes, after which the connection is terminated. It is possible to unplug the telephone and plug it into another socket on the same ISDN outlet in order to resume the call (after replugging on the S bus you need to lift the handset briefly and replace it). To park a call:

```
α 0551234567      A  
DM 0.20 terminate >>
```



```
Parked code:1    A  
2:04 terminate
```

Press the Park key during an active call.
The call is parked using the set park code (see »User settings«). The lower display line shows the current call duration.



Replace the handset.



```
Dial: -          A  
00+             >>
```

Lift the handset on another telephone or on the replugged telephone.



```
α 0551234567      A  
DM 0.30 terminate >>
```


Press the Park key
Resume the call.

- If no park code has been set, you must enter a (temporary) park code each time you park/retrieve a call.
- For instructions on programming the park codes, refer to »Entering the park code«.


Advanced features

Speed-dialling


10 speed-dialling memories are available (for all users, user-independent). You can program frequently used numbers or functions under the speed-dialling memory. For detailed information on the individual functions, refer to the relevant chapter in these Operating Instructions. To program, change or delete a speed-dialling number:




Press menu key until »Settings« is displayed



Press the Foxkey under \checkmark until »Speed dial« is shown.




Press the Foxkey under »Change«.
»Press speed-dial button« appears in the display.




Press the relevant speed dial key briefly (for numbers 1 to 5) or twice in rapid succession (for numbers 6 to 10).


The selected speed dial number is displayed (1–10). Enter, change or delete the corresponding number or function.



Enter or change the telephone number (if a function needs to be added first, continue at the next space). To enter attributes for the number, refer to the chapter entitled »Phonebook«.




To add a function, press the Foxkey under $\>>$ until »Function« is displayed.




Press the Foxkey at the appropriate place under »Function«.

The letter »F« for function is added.



Enter the desired function number (see following functions list). By pressing the Foxkey under »del« you can delete digits at the cursor position. You can press the Foxkey $\text{00} \rightarrow$ to search for and dial a number stored in the phonebook (see »Dialling from the phonebook«)



Press the Foxkey under »ok«.

You can now program another speed-dialling number.

Advanced features

- ⇒ *Sending a subaddress is only possible in on-hook dialling.*
- ⇒ *For PBX operation the number must be entered with prefix but without Exchange Access Code (EAC).*
- ⇒ *If you have not already programmed a speed-dialling number, you can call up the programming function by pressing the relevant speed-dial key.*

The attribute »Function« is used to define the following functions:

Function	Description
F01	Manual rejection of incoming calls
F02 xx..xx	Send DTMF
F03 xx..xx	Send keypad
F04 xx	Park/retrieve active connection with Code xx (valid for all users)
F06	3-party conference
F07	Call transfer
F08	Microphone off
F11 xx..xx	Direct dial
F20	3 rd connection for PBX
F21 xx..xx	Call forwarding permanent with destination xx..xx
F22 xx..xx	Call forwarding delayed with destination xx..xx
F23 xx..xx	Call forwarding on busy with destination xx..xx
F25	Switch call filter on/off for active user
F26	Switch TAM on/off for active user
F31	Activate user A
F32	Activate user B
F33	Activate user C
F34	Activate user D
F35	Activate user E

Advanced features

Malicious Call Identification (MCID)

This service must be requested from your network provider. This function allows the number of the caller and the called party to be registered by the exchange along with date and time.

Malicious calls can be registered during the call and up to 20 seconds after the caller has hung up.

⇒ *Malicious calls can only be registered with the handset off-hook (i.e. not in handsfree or listening by loudspeaker mode).*

To activate MCID:

```
No. suppressed  A
John accept    >>
```



```
«No. suppressed  A
0:01 terminate   >>
```

Lift the handset



```
«No. suppressed  A
No. suppressed MCID >>
```

Press the Foxkey under >> until »MCID« appears in the lower display line.



```
.....activated.....
```

Press the Foxkey under »MCID«. MCID is activated.

DTMF (Dual Tone Multifrequency)

Once a connection is established, the Eurit 33/33 plus automatically switches to DTMF/MFV. This allows you for example to play back TAM messages remotely.

Advanced features

Subaddresses

Subaddresses are used for remotely controlling equipment that supports subaddresses. The Eurit 33 / 33 plus does not evaluate incoming subaddresses. You can enter subaddresses during on-hook dialling as follows:



```
Dial: 0551234567_  A
00+ →00 del >>
```

Enter the number you wish to call.



```
Dial: 0551234567_  A
Subaddress Keypad >>
```

Press the Foxkey under >> .
The lower display line shows the options
»Subaddress« and »Keypad«.



```
Dial: 0551234567Z_  A
Subaddress Keypad >>
```

Press the Foxkey under »Subaddress«.
The letter »Z« is entered at the cursor position.



```
Dial: 0551234567Z23_  A
Subaddress Keypad >>
```

Enter the desired subaddress.



```
0551234567  A
terminate
```

Lift the handset or press the loudspeaker key.
The number is dialled.

➤ *Subaddresses can only be entered during on-hook dialling.*

➤ *Subaddresses in the phonebook or the speed-dialling memory can be entered using special symbols (see »Speed-dialling«).*

Send keypad

With keypad information the exchange can, for instance, activate and deactivate features. You can enter keypad information during on-hook dialling as follows:



```
Dial: 0551234567_  A
00+ →00 del >>
```

Enter the number.



```
Dial: 0551234567_  A
Subaddress Keypad >>
```

Press the Foxkey under >> .
The lower display line shows the options
»Subaddress« and »Keypad«.



```
Dial: 0551234567K_  A
Subaddress Keypad >>
```

Press the Foxkey under »Keypad«.
The letter »K« is entered at the cursor position.



```
Dial: 0551234567K12_  A
Subaddress Keypad >>
```

Enter the relevant keypad information.




```
0551234567K12  A
terminate
```

Lift the handset or press the loudspeaker key.
The number is dialled and the keypad information is sent.


Advanced features

Send mail (UUS)


You can use your Eurit 33 / 33 plus to send mails (messages up to 32 characters in length) to other subscribers (UUS = User to User Signalling). These mails are displayed on the called person's telephone without them answering the call. Mails are registered in the caller list.




Press menu key until »Functions« is displayed




Press the Foxkey under \checkmark until »DMail (UUS)« is shown.



Press the Foxkey under »Send«. Enter your text in the display.



Enter the mail text. If the text is longer than the available space, it is wrapped (...appears before the text).





Press the Foxkey under »ok«.

The message »Dial to send« appears to prompt you to enter the number.



Enter the number.

You can press the Foxkey $\text{000} \rightarrow$ to search for and dial a number stored in the phonebook (see »Dialling from the phonebook«)



Lift the handset or press the loudspeaker key. The mail is sent.

Advanced features

Info messages

You can record info messages for other users on the Eurit 33 plus. These info messages can be played back and deleted by recipients in the same way as TAM messages. Info messages are registered in the caller list.



Functions ^ A

Press the menu key until »Functions« is displayed



Info message change ^ A

Press the Foxkey under ∇ until »Info message« is shown



Recipient: John
rec << >>

Press the Foxkey under »Change«.
The active user is suggested as recipient.



Recipient: Nancy
rec << >>

Press the Foxkey under << or >> until the recipient is displayed. The telephone is ready for recording your info message.



Lift the handset
You are now ready to record your message in the handset.



Info message [rec]

Press the Foxkey under »rec«.
Ready signal is heard. Speak into the handset.



.....Replace handset.....

Press the Foxkey under ■ to end your message. A signal confirms the end of recording. You are prompted to replace the handset. The recording can also be ended by replacing the handset.



Info message change ^ A










Replace the handset.

Basic settings

The basic settings described here are telephone settings i.e. they are valid for all users.

User setup

Up to 5 users can be defined. Every user is assigned an MSN (Multiple Subscriber Number A, B, C, D, E). Your telephone rings when one of the set MSNs is called.

	Installation ^ v	Press menu key until »Installation« is displayed.
	Set MSN change ^ v	Press the Foxkey under v. »MSN« appears in the display.
	Set A MSN change ^ v	Press the Foxkey under »Change«. »MSN A« appears in the display.
	MSN A: _ ok	Press the Foxkey under »Change«.
	MSN A: 1234567 ok del	Enter the number for MSN A. Attention: Enter the MSN without prefix.
	User A: _ ok A+a	Press the Foxkey under »ok«.
	User A: Nadia_ ok a+a del	Enter the name for MSN A. If you do not enter a name, the MSN is handled as a name.
	Set A MSN change ^ v	Press the Foxkey under »ok« to confirm entry. »Set MSN A« appears again in the display.
	Set B MSN change ^ v	Press the Foxkey under v. »Set MSN B« appears in the display. Set MSN B the same way and repeat the procedure for MSN C to MSN E.

- ⤵ Your Eurit 33 / 33 plus is delivered with no user defined and is set to ring for all incoming calls.
- ⤵ To take advantage of all the functions of your Eurit 33 / 33 plus, you must define at **least one user**.
- ⤵ To allow you to determine which incoming calls are for which users, you can define different ringing melodies (see »Setting the ringing melody and volume« and »Incoming calls«).
- ⤵ For outgoing calls the MSN of the active user is also presented. If you do not wish an MSN to be presented for a specific user, you can suppress it (see »CLIR«).

Deleting users

To delete a user:

MENU
Installation

Set MSN
change

Set A MSN
change

Set E MSN
change

MSN E: 1234569
ok del

MSN E: _
ok

Remove user ?
Yes No

.....deleted.....

Press menu key until »Installation« is displayed.

Press the Foxkey under \vee .
»Set MSN« appears in the display.

Press the Foxkey under »Change«.
»Set MSN A« appears in the display.

If you do not wish to delete MSN A, press the Foxkey under \vee until you reach the MSN to be deleted.

Press the Foxkey under »Change«.

Press the Foxkey under »del« until all the MSN digits are deleted. After the last digit is deleted, »del« disappears.

Press the Foxkey under »ok«.
A prompt appears »Delete user?«.

Press the Foxkey under »Yes«.
The user is deleted. An acknowledgement appears.

⇒ When you delete a user his user settings and messages are also deleted.

Setting the date and time

When starting up your telephone or following a power cut the time display flashes. After the first outgoing and answered call the time and date are automatically updated (provided your connection supports this function). The time no longer flashes. Any discrepancies are corrected for each outgoing call. You can also set the time and date manually.



Installation ^ v

Press the menu key until »Installation« is displayed.



Date / Time
change ^ v

Press the Foxkey under v until »Date/Time« is shown.



Date: 01.01.98
change ^ v

Press the Foxkey under »change«.



Date: 11.11.98
ok

A date is indicated in the display.
Enter the date.



Time: 03:54
ok

Press the Foxkey under »ok«.
A time is indicated in the display.



Time: 11:11
ok

Enter the correct time.



Date / Time
change ^ v

Press the Foxkey under »ok«.
The display again shows »Date/Time«.

Setting the language

Your telephone is delivered with the national language preset. You can set it for German, French, Italian or English as follows:



Installation ^ v

Press menu key until »Installation« or »Installazione« appears.



Language change ^ v

Press the Foxkey under v until »Sprache« »Langue«, »Lingua« or »Language« appears.



Language: Deutsch ok Français >>

Press the Foxkey under »ändern«, »modifier«, »cambiare« or »change« .

The set language is shown in the upper display line (Deutsch, Français, Italiano or English) and one of the selectable languages in the lower display line. Press the Foxkey to display other languages >> .



Sprache: English ok Italiano >>

Press the Foxkey under the appropriate language.

The selected language appears in the upper display line and the others in the lower line.



Language change ^ v

Press the Foxkey under »ok«. The selected language is displayed.

Switching the headset on and off

The Eurit 33 / 33 plus is equipped with an interface for connecting a headset. Switch the headset on or off as follows:



Installation ^ v

Press the menu key until »Installation« is displayed.



Headset change ^ v

Press the Foxkey under v until »Headset« is shown.



Headset: off
ok on

Press the Foxkey under »change«. The upper display line shows the set status and the lower display line shows the selectable status.



Headset: on
ok off

Press the Foxkey under »on« or »off«. The newly selected status is shown in the upper display line.



Headset change ^ v

Press the Foxkey under »ok«. The headset is switched on or off as selected.

➤ If the headset is switched on, the status pictogram  indicates this in the standby display.

Basic settings

Settings for automatic redial (autodial)

For automatic redial, the number of redials and the interval between redials can be set as follows:



Installation ^ v

Press menu key until »Installation« is displayed.



Autodial
change ^ v

Press the Foxkey under v until »Autodial« is shown.



Redial: 10
change ^ v

Press the Foxkey under »change«.
The set number of redials is displayed.



Redial: 10
ok del

Press the Foxkey under »change«. The number of redials can now be overwritten.



Redial: 4_
ok del

Enter the desired number of redials (1 to 99).



Redial : 4
change ^ v

Press the Foxkey under »ok«.
The number of redials is stored.



Dial interval [s]: 60
change ^ v

Press the Foxkey under v.
The display shows the set interval between redials.



Dial interval [s]: 60
ok del

Press the Foxkey under »change«.
The interval between redials can now be overwritten.



Dial interval [s]: 90
ok del

Enter the desired interval between redials (5 to 240).



Dial interval [s]: 90
change ^ v

Press the Foxkey under »ok«.
The interval between redials is stored..

PBX settings

For settings for PBX operation, refer to the chapter entitled »PBX operation«.

Setting the contrast

You can adjust the display contrast as follows:



Installation ^ v

Press the menu key until »Installation« is displayed.



Contrast change ^ v

Press the Foxkey under v until »Contrast« is displayed.



Contrast: 000____
ok << >>

Press the Foxkey under »change«.
The upper display line shows the set contrast with a bar symbol.



Contrast: 00000__
ok << >>

Press the Foxkey under << or >> to reduce or increase the contrast.

The changed contrast is shown in the display.



Contrast change ^ v

Press the Foxkey under »ok«.
The contrast setting is saved.

Basic settings

Setting the tax factor and currency

For correct advice of charge display you must set the tax factor and currency. Your telephone is delivered with national values preset. You can change the tax factor and currency as follows, e.g. from 0.1210 DM per charge pulse to 0.1 FR.



Installation ^ v

Press the menu key until »Installation« is displayed.



Taxes change ^ v

Press the Foxkey under ∇ until »Taxes« is displayed. Press the Foxkey under »Change«.



Tax factor: 0.1210 change ^ v

»Tax factor: x.xxxx« appears in the display, where x.xxxx corresponds to the value per charge pulse (in the set currency).



Tax factor: 0.1000 ok

Change the tax factor. The cursor is positioned under the first character. Use the minus and plus keys to move the cursor.



Tax factor: 0.1000 change ^ v

Press the Foxkey under »ok«.
The tax factor is saved.



Currency: DM change ^ v

Press the Foxkey under ∇ . »Currency: xx.« appears in the display, where xx corresponds to the set currency.



Currency: DM ok del

Press the Foxkey under »change«. The currency can now be overwritten.



Currency: FR. ok del

Change the currency. The cursor is positioned under the first character. Use the minus and plus keys to move the cursor. By pressing the Foxkey under »del« you can delete characters at the cursor position.



Currency: FR. change ^ v

Press the Foxkey under »ok«.
The currency setting is saved.

⇒ *Currency and taxes are dependent on your network provider (your personal settings are ignored).*


Editing the provider list / dialling via provider

Irrespective of your network provider, you can also conduct calls via other providers if you subscribe to this service. You have the following options for automatic provider choice:


- Provider prefix dialling: All outgoing calls with this prefix are always routed through this provider (e.g. prefix »0« for long distance, »00« for abroad, »0033« for France, etc.). If no prefix is entered, all calls not otherwise defined are made through this provider.
- Link phonebook entries with provider (see »Phonebook, Entering attributes«). Outgoing calls with this number are always routed through this provider. Unlike the above option, this option is prioritised.

➤ *Automatic provider choice functions only for on-hook dialling or dialling from a list or the phonebook. It does not function with the handset lifted!*


To change the provider list:




Press menu key until »Installation« is displayed.




Press the Foxkey under \checkmark until »Provider« is shown




Press the Foxkey under »change«.
»Provider list« appears in the display.




Press the Foxkey under »Change«.
The display shows either »1:no provider« (if no provider is set) or »1:xxx (yy)«, where xxx corresponds to the provider name and yy to the provider code.



Press the Foxkey under \gg until the desired provider appears (a consecutive number is shown in front of the name).



Press the Foxkey under »change«.
You can now enter or change the provider name.



Enter or change the provider name. The cursor is positioned under the first character. Use the minus and plus keys to move the cursor. By pressing the Foxkey under »A→a« or »a→A« you can switch between lower and upper case. By pressing the Foxkey under »del« you can delete characters at the cursor position. If you delete the entire name, the entry is removed from the list.

Basic settings



```
No.: 10765
ok                               del
```

Press the Foxkey under »ok«.

You can now enter or change the provider code.



```
No.: 10775_
ok                               del
```

Enter or change the 5-digit provider code.



```
3: Telco3 (10775)
change ^ v
```

Press the Foxkey under »ok«. The provider is stored in the list.



```
Provider list
change ^ v
```

Press ESC key.

»Provider list« appears again in the display.



```
Auto. Provider choice
change ^ v
```

Press the Foxkey under v.

»Auto provider choice« appears in the display.



```
1: 00 with Telco3
change ^ v
```

Press the Foxkey under »change«.

The display shows either »1: no provider« (if no automatic provider is set) or »1:xxx (yyy)«, where xxx corresponds to the prefix and yyy to the provider name.



```
2: No entry
change ^ v
```

Press the Foxkey under v until the desired entry is shown



```
No.:
ok
```

Press the Foxkey under »change«.

You can now enter or change the prefix. If no prefix is entered, all calls not otherwise defined are routed through this provider.



```
No.: 0033_
ok                               del
```

Enter or change the prefix.



```
Provider: No Provider
ok << >>
```

Press the Foxkey under »ok«.

The display shows either »Provider: no provider« (if no provider has yet been assigned) or »Provider: xxx«, where xxx corresponds to the provider name.



```
Provider: Telco1
ok << >>
```

Press the Foxkey under >> or << until the display shows the provider via which calls with the preset area code are to be routed.



```
2: 0033 with Telco1
change ^ v
```

Press the Foxkey under »ok«.

»z:« yyy with xxx« appears, where xxx corresponds to the entry number, yyy to the provider name. If no prefix has been entered, the display shows »z:normal with xxx«.

```
2: normal with Telco1
change ^ v
```















User settings

The following settings can be defined individually for each user.

⇒ *These settings can only be made if at least one user is defined (see »Basic settings«).*

Setting the ringing melody and volume

Every user can select from seven different ringing melodies and volumes.

- | | | |
|--|---|---|
|  |  | Press the menu key until »Settings« is displayed. |
|  |  | Press the Foxkey under \checkmark until »Ringing tone« is displayed. |
|  |  | Press the Foxkey under »change«.
The display shows »Melody« followed by the current melody (default: Melody 1). |
|  |  | Press the Foxkey under \gg or \ll to select a new melody (you can also use the plus or minus keys). The selected melody is heard. |
|  |  | Press the Foxkey under »ok«. The melody setting is saved.
The upper display line shows the set volume with a bar symbol (default: medium). |
|  |  | Press the Foxkey under \gg or \ll to adjust the volume (you can also use the plus or minus keys). The melody is heard at the selected volume. |
|  |  | Press the Foxkey under »ok« once the volume is adjusted.
The display again shows »Ringing tone«. |

⇒ *Note that different melodies can be set for different users in order to distinguish incoming calls acoustically.*

⇒ *Attention: Minimum volume = ringing tone off, i.e. the symbol $\$$ »Do Not Disturb« is shown and the user LED is lit.*

⇒ *For incoming calls you can adjust the volume of the ringing tone directly by pressing the plus or minus keys.*

Switching the call filter on and off

If the call filter is activated, calls from numbers in the phonebook for which »no filter« has not been defined are rejected (the caller hears the busy signal). Only calls from numbers for which »no filter« has been set are signalled even if the call filter is activated (see »Phonebook«).

Your Eurit 33 / 33 plus is delivered with the call filter off.

Every user can switch the call filter on or off individually.



Settingss ^ A
v

Press the menu key until »Settings« is displayed.



Call filter: off
change ^ A
v

Press the Foxkey under  until the display shows »Call filter«



Call filter: off
ok on

Press the Foxkey under »change«.
The lower display line shows the selectable status.



Call filter: on
ok off

Press the Foxkey under »on« or »off«.
The newly selected status is shown in the upper display line.



Call filter: on
change ^ A
v

Press the Foxkey under »ok«.
The call filter is switched on or off as selected.

➔ *If the call filter is active, the status pictogram  indicates this in the standby display.*

CLIR (Calling Line Identification Restriction)

When you make a call, your number (i.e. your MSN) is indicated on the called person's telephone. If you are called, the caller immediately sees your number when you lift the handset.

Every user can suppress their number for outgoing and incoming calls in order to remain anonymous.



Settings

Press the menu key until »Settings« is displayed.



Suppl. services
change

Press the Foxkey under ∇ until »Suppl. services« is displayed.



CLIR: off
change

Press the Foxkey under »change«. »CLIR« is shown in the display, followed by the actual setting »off« or »on«.



CLIR: off
ok on

Press the Foxkey under »change«. The lower display line shows the selectable status.



CLIR: on
ok off

Press the Foxkey under »on« or »off«. The newly selected status is shown in the upper display line.



CLIR: off
change

Press the Foxkey under »ok«. The number is suppressed or presented as selected.

➤ If the number is suppressed, the status pictogram ∇ indicates this in the standby display.

Call waiting

During a call another incoming call is acoustically signalled. For further information on »Call waiting«, refer to »Advanced features«.

Every user can suppress »Call waiting« in order to remain undisturbed during an active call.



```
Settings      ^ v A
```

Press the menu key until »Settings« is displayed.



```
Suppl. services ^ v A  
change
```

Press the Foxkey under ∇ until »Suppl. services« is displayed.



```
CLIR: off ^ v A  
change
```

Press the Foxkey under »change«. »CLIR« is shown in the display, followed by the actual setting »off« or »on«.



```
Call waiting: on ^ v A  
change
```

Press the Foxkey under ∇ until the display shows »Call waiting« followed by the actual setting »off« or »on«



```
Call waiting: on ^ v A  
ok off
```

Press the Foxkey under »change«. The lower display line shows the selectable status.



```
Call waiting: off ^ v A  
ok on
```

Press the Foxkey under »on« or »off«. The newly selected status is shown in the upper display line.



```
Call waiting: off ^ v A  
change
```

Press the Foxkey under »ok«. »Call waiting« is suppressed or signalled as selected.

Entering the park code

Every user can program his own park code if he wishes to park calls using a code other than the default code 1.



```
Settings      ^  A
```

Press the menu key until »Settings« is displayed.



```
Suppl. services  ^  A  
change
```

Press the Foxkey under ∇ until »Suppl. services« is displayed.



```
CLIR: off      ^  A  
change
```

Press the Foxkey under »change«. »CLIR« is shown in the display, followed by the actual setting »off« or »on«.



```
Park code: 1   ^  A  
change
```

Press the Foxkey under ∇ until »Park code« is shown followed by the actual park code.



```
Park code: 1   ^  A  
ok             del
```

Press the Foxkey under »change«. You can now enter or change the desired park code.



```
Park code: 34_ ^  A  
ok             del
```

Enter or change the park code. The cursor is positioned under the first digit. Use the minus and plus keys to move the cursor. By pressing the Foxkey under »del« you can delete characters at the cursor position.



```
Park code: 34 ^  A  
change
```

Press the Foxkey under »ok«. The new park code for this user is set.

Eurit 33 plus telephone answering machine (TAM)

Introduction

Your **Eurit 33 plus** comes with an integrated telephone answering device (TAM). Greetings (outgoing announcements) and incoming messages are digitally stored i.e. the TAM requires no magnetic recording tape and hence no maintenance. All messages can be played back quickly and simply. The entire recording time for greetings and incoming messages depends on the set recording quality (see »Recording quality/recording time«). The maximum recording time is approximately 22 minutes.

The TAM can be set for individual users:

Every user can

- activate and deactivate the TAM individually.
- select either »Answer and record« or »Answer only« mode.
- set one of five personal greetings or the default greeting.
- define a variety of TAM settings.

- ⇒ *If you press the menu key and hold it down, the TAM is activated and deactivated **for all users.***
- ⇒ *If the recording capacity is full, no more messages can be recorded. The message »TAM full« appears in the display. You must delete old messages (see »Deleting messages«).*
- ⇒ *If there is a power failure, recorded greetings and incoming messages are saved.*
- ⇒ *In emergency mode the TAM does not function.*

Activating/deactivating the TAM for all users



Greeting A: 1 [▶]

Activating the TAM

Press the menu key and hold it down until the TAM is activated.

The TAM LED is lit and the greetings are played. If no personal greetings have been recorded, the default greeting is heard (see »Default greeting«).



21.01.99 17:36 A
31<5> >>

Press the Foxkey under ■ to interrupt playback. The status pictogram ☉ is shown in the display. The TAM is ready.



...☉TAM ABCDE:off...

Deactivating the TAM

Press the menu key and hold it down until the TAM is deactivated.

The TAM LED goes off and the adjacent display appears. The status pictogram ☉ disappears. The TAM is deactivated for all users.

Activating / deactivating the TAM for individual users



Settings ^ v A

Activating the TAM individually

Press menu key until »Settings« is displayed.



☉TAM: off ^ v A
change on ^ v

Press the Foxkey under v until the display shows »☉TAM« followed by the current setting, »off«.



Greeting A: 1 [▶]

Press the Foxkey under »on«.

The TAM LED is lit and the greetings are played back. If no personal greetings have been recorded, the default greeting is heard (see »Default greeting«).

Eurit 33 plus telephone answering machine (TAM))



21.01.99 17:36
31<5>

Press the Foxkey under ■ to interrupt playback. The status pictogram ☉ is shown in the display. The TAM is ready for the active user.



Settings

Press the menu key until »Settings« is displayed.



☉TAM: on
change off

Press the Foxkey under ∨ until the display shows »☉TAM«, followed by the current setting, »on«.



☉TAM: off
change off

Press the Foxkey under »off«. The TAM is deactivated for the active user. The status pictogram ☉ disappears.

- ☞ You can also activate and deactivate the TAM using speed-dialling (for the active user) (see »Speed-dialling«).

Call acceptance

You can accept incoming calls even if your TAM is switched on, your greeting being played or the caller recording a message.



During your greeting or while the caller is recording a message, lift the handset and talk.

- ☞ The message being recorded when the call is accepted is stored.

Eurit 33 plus telephone answering machine (TAM)

Greetings

You can record up to 5 greetings on your Eurit 33 plus. The 5 greetings are available to all users. Every greeting can be up to 3 minutes long.

Default greeting

You can also activate your TAM without recording your own greeting, since the Eurit 33 plus is delivered with a default greeting. »Unfortunately there is no one available right now to answer your call. Please leave a message after the tone. Thank you.«

Once you have recorded all 5 greetings, the default message is no longer available. If you delete one of the recorded greetings, the default greeting is restored.

Recording greetings

You can record greetings whether the TAM is on or off.



Settins

Press the menu key until »Settings« is displayed.



@TAM: on
change on

Press the Foxkey under ∇ until the display shows »@TAM«, followed by the current setting »off« or »on«.



Greetings: 1 Type: \updownarrow
change

Press the Foxkey under »change«.
The display shows the operating type for the first greeting:

\uparrow **Answer only** (the caller hears the greeting but cannot leave a message)

\updownarrow **Answer and record** (the caller hears the greeting and can leave a message after the beep).

Greetings: 1 none
change

If you have not recorded a greeting, »none« is displayed.



Greetings: 1 Type: \updownarrow
ok << >> \updownarrow \blacktriangleright rec

Press the Foxkey under »change«.
The telephone is ready for recording a greeting.



Greetings: 3 Type: \updownarrow
ok << >> \updownarrow \blacktriangleright rec

Press the Foxkey under \blacktriangleright until the desired greeting (1 to 5) is shown.

Eurit 33 plus telephone answering machine (TAM)



```
Greetings: 3 [▶]
■
```

By pressing the Foxkey under ▶ you can listen to the greetings saved under this number (if »none«, the default greeting is heard).



Lift the handset (the greeting can only be recorded with the handset off-hook).



```
Greetings: 3 Type: ⚡
ok << >> ⚡ ▶ rec
```

Press the Foxkey under »rec«. Ready signal is heard. Speak.



```
Greetings: 3 [rec]
■
```

Press the Foxkey under ■ to end your message. A signal confirms the end of recording. The recording can also be ended by replacing the handset.



```
Greetings: 3 Type: ⚡
ok << >> ⚡ ▶ rec
```

Press the Foxkey under ⚡ or ⚡ to set the type. If necessary, repeat the procedure to record further greetings.



```
Greetings: 3 Type: ⚡
change ^ v
```

Press the Foxkey under »ok«. The recording is finished. The greeting is assigned to the active user.



Replace the handset.

- ↪ *The default setting for the greeting type is »Answer and record«.*
- ↪ *If the message memory is full, callers can no longer record messages. The TAM LED flashes quickly. You must delete messages (see »Deleting messages« and »TAM remote access«).*
- ↪ *To allow your TAM to store more messages, you can limit the length of the messages. If you have not set a time limit, an incoming message can be »infinitely« long (see »Message length«).*

Eurit 33 plus telephone answering machine (TAM)

Selecting / playing back the greeting

Once greetings have been recorded, every user can select and set the greeting that best suits the situation.



```
21.01.99      17:35 C
  1(5)      >>
```

Select user (see »Changing users«).



```
Settings      C
      ^  v
```

Press the menu key until »Settings« is displayed



```
@TAM: on      C
change off    ^  v
```

Press the Foxkey under \downarrow until the display shows »@TAM«, followed by the current setting »off« or »on«.



```
Greetings: 1 Type: 1 C
change      ^  v
```

Press the Foxkey under »change«.
The display shows the selected greeting and type.



```
Greetings: 1 Type: 1 C
ok << >>  1 2 rec
```

Press the Foxkey under »change«.
The lower display line shows the various options.



```
Greetings: 3 Type: 1 C
ok << >>  1 2 rec
```

Press the Foxkey under \gg until the desired greeting (1 to 5) is shown.



```
Greetings C: 1      [▶]
      ■             del
```

To check the greeting, press the Foxkey under \blacktriangleright .



```
Greetings: 3 Type: 1 C
change      ^  v
```

Press the Foxkey under »ok«.
The greeting is assigned to the active user.

↪ You can interrupt the playback of a greeting by pressing the Foxkey under ■.

↪ During playback press the arrow keys (plus or minus key) to adjust the volume.

Eurit 33 plus telephone answering machine (TAM)

Deleting / changing greetings

You can delete recorded greetings and replace them with a new one.



```
21.01.99      17:35 C
  1(5)          >>
```

Select user (see »Changing users«).



```
Settings      C
              ^  v
```

Press the menu key until »Settings« is displayed



```
@TAM: on      C
change off    ^  v
```

Press the Foxkey under \vee until the display shows »@TAM«, followed by the current setting »off« or »on«.



```
Greetings: 3  Type: 1  C
change        ^  v
```

Press the Foxkey under »change«. The display shows the selected greeting and type.



```
Greetings: 3  Art: 1
ok << >>  ↑  ▸  rec
```

Press the Foxkey under »change«. The lower display line shows the various options.



```
Greetings C: 1      [1]
                ■    del
```

To check the greeting, press the Foxkey under \blacktriangleright .



```
.....deleted.....
```

Press the Foxkey under »del«. The greeting is deleted. An acknowledgement appears.



```
Greetings: 3  none
ok << >>  ↑  ▸  rec
```

To select additional greetings for deletion in the same way, press the Foxkey under \ll or \gg .



```
Greetings: 3  none  C
change        ^  v
```

Press the Foxkey under »ok«. If »none« is shown, the user is assigned the default greeting.

➤ To re-record a deleted greeting, please refer to »Recording greetings«.

Eurit 33 plus telephone answering machine (TAM)

Incoming messages

Incoming messages are stored in the message memory of the relevant user depending on the corresponding MSN. The flashing TAM LED and display alert the user to new messages on his personal TAM.

Incoming messages are stored in the caller list in the same way as unanswered calls. Up to 30 calls are stored in the caller list (for all users). You can use the caller list to call back or check who has been trying to call you. The display also shows the date and time of the messages (see »Dialling from the caller list«).

Telephoning during recording of an incoming message

You can also make a call while a message is being recorded:



Press R key.



Enter the number.



Lift the handset or press the loudspeaker key. The number is dialled.

Message playback

Incoming messages can be played back whether or not the TAM is on. The handset must be on-hook before message playback begins, after which messages can also be listened to over the handset. Every user can play back the messages intended for him. All incoming messages are played back, whether they have already been listened to or not. Playback is in chronological order (»oldest« message first).



21.01.99	14:15	A
03/4	38<10>	>>
0551234567	14:10	
■ K<	>>	del
0551234567	14.01. 14:10	
■ K<	>>	del
0033123..090	14.01. 14:10	
■ K<	>>	i del
Newman John	14.01. 14:10	
■ K<	>>	i del

Press the Foxkey under »x/y« to play back your own messages (x = number of new messages for the active user, y = total message count for the active user). Playback of all incoming messages for the active user begins.

The display shows the number or name (if stored in the phonebook) and the date (if message received before the current date) as well as the time of the first incoming message.

↳ If the number is too long, it is wrapped (this also applies to the name). Press the Foxkey under »i« to display additional information.

Eurit 33 plus telephone answering machine (TAM)

Functions during playback



Press the Foxkey under ■ to stop playback. The standby display is resumed.



Pressing the Foxkey under K<< or >>K has the following effect:

- Press once briefly. Skip to start of last or next message.
- Hold down: Scroll backwards or forwards. When the start of a message is reached, the message is played back.



Press the Foxkey under »del« to delete the message. You can also delete a message without listening to it.

Deleting messages

Deleting messages during playback

```
21.01.99      14:15  A
03/4      38(10)  >>
```



```
0552546111      14:10
■ K< >X      del
```



```
.....deleted.....
```



```
Newman John      14:10
■ K< >X      i      del
```

```
21.01.99      14:16  A
02/3      38(10)  >>
```

Press the Foxkey under » 0x/y « to play back your own messages (x = number of new messages for the active user, y = total message count for the active user).

During playback of the message you wish to delete, press the Foxkey under »del«. The message is deleted. An acknowledgement appears.

The next message is played back. If no other messages are available, playback is ended.

The message count in the lower display line is updated. To delete additional messages, repeat the procedure.

Deleting messages in the caller list

```
21.01.99      14:15  A
03/4      38(10)  >>
```



```
0551234567      A
del  #00  0/i      ^      v
```

Press the Foxkey under » 3x(y) « to call up your personal caller list (x = number of calls for active user, y = total call count for all users).

The display shows the number of the most recent incoming call or, if this is stored in the phonebook, the caller's name. If the caller has left a message, this is indicated in the display line » 0/i «.



```
Delete message ?
No      Yes
```

Press the Foxkey under »del«. A prompt appears.












```
.....deleted.....
```

Press the Foxkey under »Yes«. The message and entry in the caller list are deleted. An acknowledgement appears.

Eurit 33 plus telephone answering machine (TAM)

Ring count / economy function

The number of rings after which the TAM is activated can be set from 0 to 9. Your telephone is delivered with the default number of rings as 4 and the economy function on.



















	<pre>21.01.99 17:35 B 31<5> >></pre>	Select user (see »Change user«).
	<pre>Settings B ^ v</pre>	Press the menu key until »Settings« is displayed
	<pre>@TAM: on B change off ^ v</pre>	Press the Foxkey under \vee until the display shows »@TAM«, followed by the current setting »off« or »on«.
	<pre>Greetings: 1 Type: 1 B change ^ v</pre>	Press the Foxkey under »change«. The display shows the selected greeting and type.
	<pre>No. of rings:4 Save B change ^ v</pre>	Press the Foxkey under \vee until »No. of rings« is displayed.
	<pre>Rings: 4 Ring save:on ok << >> off</pre>	Press the Foxkey under »change«. The lower display line shows the various options.
	<pre>Rings: 8 Ring save:on ok << >> off</pre>	Press the Foxkey under \ll or \gg until the desired number of rings is displayed.
	<pre>Rings: 8 Ring save:on ok << >> on</pre>	Press the Foxkey under »off« or »on« to switch the economy function off or on. The newly selected status is shown in the upper display line.
	<pre>No. of rings: 8 B change ^ v</pre>	Press the Foxkey under »ok«. The setting is defined.

- ⇒ *Economy function (save): For remote playback of messages, the TAM seizes the line two rings earlier than the set number of rings. If additional rings are heard, no new messages have been recorded and you can abort the remote interrogation procedure prematurely and save the cost of the call.*

Eurit 33 plus telephone answering machine (TAM)

Message length / listen

To enable your TAM to store more messages, the length of incoming messages can be limited to 30, 60, 120 or 180 seconds. If the message length is not limited, a message can be »infinitely« long. To listen in to messages over the Eurit 33 plus microphone as they are recorded, »Listen« must be activated.

- | | | |
|--|---|---|
|  |  | Select user (see »Change user«). |
|  |  | Press menu key until »Settings« is displayed |
|  |  | Press the Foxkey under \surd until the display shows »eTAM«, followed by the current setting »off« or »on«. |
|  |  | Press the Foxkey under »change«.
The display shows the selected greeting and type. |
|  |  | Press the Foxkey under \surd until »Record« is shown |
|  |  | Press the Foxkey under »change«.
The lower display line shows the various options. |
|  |  | Press the Foxkey under << or >> until the desired message length is displayed: infinite, 30s, 60s, 120s and 180s). |
|  |  | Press the Foxkey under »off« or »on« to switch the call monitoring function off or on.
The newly selected status is shown in the upper display line. |
|  |  | Press the Foxkey under »ok«.
The setting is defined. |

➤ Your telephone is delivered with the message length as 60 seconds and the »Listen« function on.

Eurit 33 plus telephone answering machine (TAM)

Recording quality / recording time

The recording quality of messages is dependent on the set recording time.

- **high** recording quality for a selected recording time of 10 minutes.
- **medium** recording quality for a selected recording time of 15 minutes.
- **normal** recording quality for a selected recording time of 22 minutes.

Your Eurit 33 plus is delivered with a high recording quality set. You therefore have a total recording time of 10 minutes (for all users together).

You can increase the recording time as follows:



```
Settings          ^  v
```

Press the menu key until »Settings« is displayed.



```
@TAM on          ^  v  
change off
```

Press the Foxkey under ∇ until the display shows »@TAM«, followed by the current setting »off« or »on«.



```
Greetings: 1 Type: 1 ^  v  
change
```

Press the Foxkey under »change«.
The display shows the selected greeting and type.



```
TAM capacity:    10min  
change           ^  v
```

Press the Foxkey under ∇ until the display shows »TAM capacity«, followed by the actual recording time.



```
TAM capacity:    10min  
ok 15min 22min
```

Press the Foxkey under »change«.
The lower display line offers various recording time options.



```
TAM capacity:    22min  
ok 10min 15min
```

Press the Foxkey under the appropriate time.
The value is shown in the upper display line.



```
TAM capacity:    22min  
change           ^  v
```



















Press the Foxkey under »ok«.
The setting is defined.

- ⇒ *Greetings are always recorded and played back at high quality.*
- ⇒ *Playback is also fully comprehensible at normal recording quality.*

Eurit 33 plus telephone answering machine (TAM)

Recording the closing message

You can record a closing message whether the TAM is on or off. The closing message is played back after the set recording time for a message has expired (the closing message is identical for all users).

- | | | |
|--|---|--|
|  |  | Press the menu key until »Settings« is displayed |
|  |  | Press the Foxkey under \vee until the display shows »@TAM«, followed by the current setting »off« or »on«. |
|  |  | Press the Foxkey under »change«.
The display shows the selected greeting and type. |
|  |  | Press the Foxkey under \vee until »Closing message« is shown |
|  |  | Press the Foxkey under »change«.
The telephone is ready for recording a closing message. \blacktriangleright (play) is only shown if a closing message has already been recorded. |
|  | | Lift the handset (the closing message can only be recorded with the handset off-hook). |
|  |  | Press the Foxkey under »rec«.
Ready signal is heard. Recording the closing message. |
|  |  | Press the Foxkey under \blacksquare to end your message.
A signal confirms the end of recording. The recording can also be ended by replacing the handset. |
|  |  | Press the Foxkey under »ok«.
The recording is finished. |
|  | | Replace the handset. |

Introduction

You can call up and remotely control your TAM from any telephone i.e.

- Listen to and delete messages
- Switch the TAM on or off
- Record or change greetings.

DTMF is used for remote access to the TAM. You can perform the required procedure either with a telephone with DTMF or multi-frequency dialling function, or with a code sender (handheld transmitter).

Note that for remote access:

- Remote access of the TAM functions only if a remote access PIN code has been activated.
- Remote access of the TAM is terminated when you replace the handset.
- Pauses between entering digits must be no longer than 9 seconds, otherwise the remote access procedure is aborted.
- To resume to basic remote access status or abort a function, press key 2.
- The remote access PIN code must be entered while the greeting is being played.

⇒ *Attention: »Call forwarding permanent« must be deactivated, otherwise your remote access call will be directly forwarded to the defined number (see »Call forwarding«).*

Setting the PIN-Code

The PIN code for remote access is valid for all users.



Installation ^ v

Press the menu key until »Installation« is displayed.



Remote access change ^ v

Press the Foxkey under v until »Remote access« is shown



Surveillance: off change ^ v

Press the Foxkey under »change«.
»Surveillance« is shown in the display, followed by the actual setting »off« or »on«.



Remote access PIN change ^ v

Press the Foxkey under v until »Remote access PIN« is shown.



Old PIN: _ ok

Press the Foxkey under »change«.
»Old PIN:« appears.



Old PIN: 0000_ ok

Enter the default PIN 0000 or, if you have already changed the PIN code, the last valid PIN code.



New PIN: _ ok

Press the Foxkey under »ok«.
»New PIN:« appears.



New PIN: 9999_ ok

Enter the new PIN code.
The PIN code must have four digits.



Remote access PIN change ^ v

Press the Foxkey under »ok«.
The new PIN code is saved.

- ⇒ *Note down your PIN code for safety. If you forget your PIN code, you can no longer initiate remote access. You must reset the PIN code to the default code 0000 (see »Reset functions«).*
- ⇒ *If you do not wish to permit remote access (block remote access), set the PIN code to 0000.*

Setting up a connection to the TAM

When TAM is activated



Enter the number. The set greeting is played back, after which a signal is heard.



Enter the PIN code during the greeting. The greeting is interrupted after the first digit of the PIN code is entered. (If an incorrect code is entered, an error signal is heard. Enter the complete code again).

Remote access standby is set up. You can now perform various functions by entering the relevant digits (see »Remote access functions«).

When TAM is deactivated



Enter the number. Let your telephone ring. After the set number of rings the TAM automatically answers (no greeting is played). A signal tone is heard.



Enter PIN code. An acknowledgement tone is heard.

- *If you enter the wrong PIN code 3 times, the connection is broken.*
- *After entering the PIN code you automatically hear your messages (or the help message, if available).*
- *If a direct access number has been programmed, the TAM immediately plays back the messages.*

Remote access with economy function

Your Eurit 33 plus is delivered with the economy function activated and the number of rings set for 4.

You can determine from the number of rings whether there are new messages on your TAM.

- If the TAM answers after 2 rings, there are new messages.
- If it continues to ring, there are no new messages. You can then hang up before the line is connected and save the cost of the call
- After 4 rings (or the number of rings set by you), the TAM answers even if no new messages have been left.

Remote access functions

Once the connection to the TAM is established, you can enter digits to perform one or more remote access functions. Once a function is ended you can select additional functions. For details see the following functions list:

Remote activation / deactivation of TAM

**Remote activation of TAM for one user:**

Press key 4. As confirmation, the greeting is played back (press key 2 to interrupt the greeting).

**Remote deactivation of TAM for one user:**

Press key 6.

**Remote activation of TAM for all users:**

Press key #, then key 4. As confirmation, the greeting is played back (press key 2 to interrupt the greeting).

**Remote deactivation of TAM for all users:**

Press key #, then key 6

Changing users

After changing users you will hear an acknowledgement signal.

**Switch to user A:**

Press key *, then key 1.

**Switch to user B:**

Press key *, then key 2.

**Switch to user C:**

Press key *, then key 3.

**Switch to user D:**

Press key *, then key 4.

**Switch to user E:**

Press key *, then key 5.

Incoming messages



Play back a user's messages:

Press key 3.



Play back all users' messages :

Press key #, then key 3.



Skip back to start of message (repeat message)

Press key 1 during playback.



Skip back to start of previous message

Press key 1 twice during playback.



Skip forward to next message:

Press key 3 during playback.



Delete current message:

Press key 0 during playback.



Delete all a user's messages:

Press key 0.



Delete all users' messages:

Press key #, then key 0 twice.



Greetings



Listen to all greetings:

Press key 7.



Repeat greeting:

Press key 1 during playback.



Skip back to start of previous greeting:

Press key 1 twice during playback.



Skip forward to next greeting:

Press key 3 during playback.



Assign active greeting to current user:

Press key 4 during playback.



Record new greeting:

Press key 5 during playback.

Record your new greeting after the acknowledgement signal (the old greeting is deleted).

Press key 5 to end recording.



Set current greeting type to »Answer and record«

During playback press key 7, followed by key 4.



Set current greeting type to »Answer only«

During playback press key 7, followed by key 6.

Call forwarding



Activate »Call forwarding permanent«

Press key 9 followed by key 7 then key 4.
Enter the destination number if not already programmed.
Conclude entry by pressing key #.



Activate »Call forwarding on delayed«

Press key 9 followed by key 8 then key 4.
Enter the destination number if not already programmed.
Conclude entry by pressing key #.



Activate »Call forwarding on busy«

Press key 9 followed by key 9 then key 4.



Deactivate »Call forwarding permanent«

Press key 9 followed by key 7 then key 6.



Deactivate »Call forwarding delayed«:

Press key 9 followed by key 8 then key 6.



Deactivate »Call forwarding on busy«

Press key 9 followed by key 9 then key 6.



Deactivate all call forwarding options

Press key 9, then key 6.

Surveillance



Activating room surveillance

Press key 8, then key 7.



Deactivating room surveillance

Press key 2.



Activating room intercom

(activate loudspeaker and microphone on telephone):
Press key 8, then key 8.



Deactivating room intercom

Press key 2.

Setting room surveillance

To activate room surveillance by remote access (remote activation of telephone microphone), the Surveillance function must be on.



Installation ^ v

Press the menu key until »Installation« is displayed.



Remote access
change ^ v

Press the Foxkey under v until »Remote access« is shown.



Surveillance: off
change ^ v

Press the Foxkey under »change«.
»Surveillance« is shown in the display, followed by the current setting »off« or »on«.



Surveillance: off
ok on

Press the Foxkey under »change«.
The lower display line shows the selectable status.



Surveillance: on
ok off

Press the Foxkey under »on« or »off«.
The newly selected status is shown in the upper display line.



Surveillance: on
change ^ v

Press the Foxkey under »ok«.
The surveillance function is switched on or off as selected.

Setting a direct access number

If you set a direct access number, all new messages are played during remote access.



Installation ^ v

Press the menu key until »Installation« is displayed



Remote access change ^ v

Press the Foxkey under v until »Remote access« is shown



Surveillance: off change ^ v

Press the Foxkey under »change«.
»Surveillance« is shown in the display, followed by the current setting »off« or »on«.



VIP No. change ^ v

Press the Foxkey under v until the display shows »VIP No.«.



VIP No.: _ ok 00 →

Press the Foxkey under »change«.
»VIP No.« appears.



VIP No.: 0551234567_ del

Enter the direct access number.



VIP No. change ^ v

Press the Foxkey under »ok«.
The direct access number is stored.

Eurit 33 plus remote access

Setting the number of rings for automatic remote activation of the TAM

Your Eurit 33 plus is delivered with the settings for automatic activation of the deactivated TAM after 15 rings. You can set a different number of rings.



```
Installation      ^  v
```

Press the menu key until »Installation« is displayed.



```
Remote access    ^  v  
change
```

Press the Foxkey under \vee until »Remote access« is shown.



```
Surveillance: off ^  v  
change
```

Press the Foxkey under »change«.
»Surveillance« is shown in the display, followed by the current setting »off« or »on«.



```
Remote access rings:15 ^  v  
change
```

Press the Foxkey under \vee until »Remote access rings« is displayed.



```
No. of rings: 15  
ok << >>
```

Press the Foxkey under »change«.
»No. of rings« appears followed by the actual number.



```
No. of rings: 10  
ok << >>
```

Press the Foxkey under \gg or \ll to select a new number of rings for autom. remote activation of the TAM (you can also use the plus or minus keys).




```
Remote access rings:10 ^  v  
change
```

Press the Foxkey under »OK«.
The setting is defined.


➤ *The number of rings for automatic remote activation can be set from 10 to 30.*

Recording a help message


To support remote access you can record a help message. This help message is played back after you enter your PIN code.




Press the menu key until »Installation« is displayed.




Press the Foxkey under \vee until »Remote access« is shown.



Press the Foxkey under »change«.
»Surveillance« is shown in the display, followed by the current setting »off« or »on«.




Press the Foxkey under \vee until »(TAM Help message TAM)« is shown




Press the Foxkey under »change«.
The telephone is ready for recording your help message. ▶ (play) is only shown if a help message has already been recorded.




Lift the handset (the help message can only be recorded with the handset off-hook).



Press the Foxkey under »rec«.
Ready signal is heard. Record the help message



Press the Foxkey under ■ to end your message.
A signal confirms the end of recording. The recording can also be ended by replacing the handset.



Press the Foxkey under »ok«.
The recording is finished.















Replace the handset.

PBX operation

When operating the Eurit 33 / 33 plus in conjunction with a PBX there are special aspects to take into account. For further information, refer to your PBX operating instructions.

Setting the Exchange Access Code (EAC)

When operating your telephone in conjunction with a PBX without automatic external line selection, the EAC may need to be set as follows:

		Press the menu key until »Installation« is displayed.
		Press the Foxkey under \surd until »PBX« appears.
		Press the Foxkey under »change«. »Exch. acc. code (EAC) : xxx« appears in the display (xxx corresponds to the current setting).
		Press the Foxkey under »change«. You can now enter or change the EAC.
		Enter or edit the EAC (maximum 4 digits).
		Press the Foxkey under »ok«. The EAC is saved.

- If you have set an EAC, you must always enter numbers in the phonebook with the prefix but without EAC (as with numbers for speed-dialling) . For emergency or service numbers, enter »X« before the number (forced insertion of EAC). See also »Phonebook«.
- If you have set an EAC, internal and external calls are automatically distinguished. The ringing tone for an external call is signalled by a short interruption of the normal ringing tone.
- When dialling from the keypad the EAC is not automatically selected.

PBX operation

Incoming EAC

Some PBXs automatically insert the EAC for incoming calls. In this case »Incoming EAC« must be activated so that, for example, numbers from the caller list can be correctly selected.

➤ You can check whether you need to make this setting by having someone external call you (after you have entered an EAC) and not answering the call. If the EAC appears twice before the caller's number (attention: »0« in the prefix is not an EAC), »Incoming EAC« must be activated.



Installation ^ v

Press the menu key until »Installation« is displayed.



PBX change ^ v

Press the Foxkey under v until »PBX« is shown.



Exch. acc. code (EAC): 0 change ^ v

Press the Foxkey under »change«.
»Exch. acc. code (EAC): xxx« appears in the display (xxx corresponds to the current setting).



Incoming EAC: off change ^ v

Press the Foxkey under v until »Incoming EAC off« or »Incoming EAC: on« is shown.



Incoming EAC: off ok on

Press the Foxkey under »change«.
The lower display line shows the selectable status.



Incoming EAC: on ok off

Press the Foxkey under »on «or »off«.
The newly selected status is shown in the upper display line.



Incoming EAC: on change ^ v

Press the Foxkey under »ok«.
The setting is saved.

PBX operation

Setting the transfer type

This obligatory transfer type setting (EURO or Disconnect) depends on your PBX.

- You can find out how to make this setting by attempting to connect your two call partners during an enquiry call (see »Call transfer«). If call transfer is not possible you must change the type from »EURO« to »Disconnect«.



Installation ^ v

Press the menu key until »Installation« is displayed.



PBX change ^ v

Press the Foxkey under v until »PBX« is shown.



Exch. acc. code (EAC): 0 change ^ v

Press the Foxkey under »change«.
»Exch. acc. code (EAC): 0« appears in the display (0 corresponds to the current setting).



Connect: EURO change ^ v

Press the Foxkey under v until »Connect« is shown. »EURO« or »Disconnect« appears.



Connect: EURO ok Disconnect

Press the Foxkey under »change«.
The lower display line shows the selectable status.



Connect: Disconnect ok EURO

Press the Foxkey under »Disconnect «or »EURO«.
The newly selected status is shown in the upper display line.



Connect: Disconnect change ^ v

Press the Foxkey under »ok«.
The setting is saved.

PBX operation

Call transfer on-hook

You can set your Eurit 33 / 33 plus to transfer a call on replacing the handset. To make this setting:



Installation ^ v

Press the menu key until »Installation« is displayed.



PBX change ^ v

Press the Foxkey under v until »PBX« appears.



Exch. acc. code (EAC): 0 change ^ v

Press the Foxkey under »change«.
»Exch. acc. code (EAC): xxx« appears in the display (xxx corresponds to the current setting).



Transfer on-hook: off change ^ v

Press the Foxkey under v until »Transfer on-hook off« or »Transfer on-hook on« is shown.



Transfer on-hook: off ok on

Press the Foxkey under »change«.
The lower display line shows the selectable status.



Transfer on-hook: on ok off

Press the Foxkey under »on« or »off«.
The newly selected status is shown in the upper display line.



Transfer on-hook: on change ^ v






Press the Foxkey under »ok«.
The setting is saved.

- »Transfer on-hook: off« (default) means: the active call is disconnected when the handset is replaced; the held call is signalled.
- »Transfer on-hook: on« means: the call is transferred when the handset is replaced.

Keypad information

Keypad information is used in conjunction with a PBX to control functions. The exchange can also activate and deactivate features.

For further information, refer to your PBX manual.



↳ You can also program keypad information with speed-dialling, see »Speed-dialling«.

Keypad before dialling

Press the asterisk or hash key first. The telephone automatically switches to keypad signalling (automatic switchover to keypad can be deactivated - see »Sending the keypad automatically«).

Enter the relevant keypad information.

Lift the handset or press the loudspeaker key. The keypad is sent.

Keypad during a call

Press the Foxkey under >> until »Keypad« appears.

Press the Foxkey under »Keypad«.

Enter the relevant keypad information. The keypad is sent.

Sending the keypad automatically

If the asterisk or hash key are pressed first, the telephone automatically switches to keypad signalling (»Keypad auto.: on«). For some systems (e.g. systems in which automatic external line selection is activated) you must deactivate automatic switchover to keypad signalling (»Keypad auto.: off«), in order, for example, to make an internal call using the asterisk key.



Installation ^ v

Press the menu key until »Installation« is displayed.



PBX change ^ v

Press the Foxkey under v until »PBX« appears.



Exch. acc. code (EAC): 0 change ^ v

Press the Foxkey under »Change«.
»Exch. acc. code (EAC): xxx« appears in the display (xxx corresponds to the current setting).



Keypad auto.: on change ^ v

Press the Foxkey under v until »Keypad auto: on or off« is shown.



Keypad auto.: on ok off

Press the Foxkey under »change«.
The lower display line shows the selectable status.



Keypad auto.: off ok on

Press the Foxkey under »on« or »off«.
The newly selected status is shown in the upper display line.







Keypad auto.: off change ^ v

Press the Foxkey under »ok«.
The setting is saved.

Reset functions

Resetting the telephone to default





You can reset the telephone to default as follows:

	Installation ^ v	Press the menu key until »Installation« is displayed.
	Service menu ^ v	Press key 1. »Service menu« appears in the display.
	Reset full execute ^ v	Press the Foxkey under v until »Reset full« is displayed.
deleted.....	Press the Foxkey under »execute«. The telephone is reset to default. An acknowledgement is shown for 5 seconds.

➤ *All settings and phonebook entries in all memories are deleted.*

Deleting the phonebook

You can delete all phonebook entries as follows:

	Installation ^ v	Press the menu key until »Installation« is displayed.
	Service menu ^ v	Press key 1. »Service menu« appears in the display.
	Reset Phonebook execute ^ v	Press the Foxkey under v until »Reset phonebook« is shown
deleted.....	Press the Foxkey under »execute«. The phonebook is deleted. An acknowledgement message is shown for 5 seconds.

➤ *Only the phonebook entries are deleted. All other settings remain unchanged.*

Reset functions

Deleting the remote access PIN

You can delete the PIN code for remote access to the TAM as follows:



Installation ^ v

Press the menu key until »Installation« is displayed.



Service menu ^ v

Press key 1.
»Service menu« appears in the display.



Reset PIN execute ^ v

Press the Foxkey under v until »Reset PIN« is shown.



.....deleted.....

Press the Foxkey under »execute«.
The PIN code for remote operation of the TAM is reset to the default 0000. An acknowledgement is shown for 5 seconds.

Resetting the TAM

You can reset the TAM to default as follows:



Installation ^ v

Press the menu key until »Installation« is displayed.



Service menu ^ v

Press key 1.
»Service menu« appears in the display.



Reset TAM execute ^ v

Press the Foxkey under v until »Reset TAM« is shown.



.....deleted.....

Press the Foxkey under »execute«.
The TAM is reset. An acknowledgement message is shown for 5 seconds.

⇒ All announcements, messages and settings for the TAM are deleted.

Reset functions

Deleting the parameters

You can delete (reset to default) all user parameters as follows:



Installation ^ v

Press the menu key until »Installation« is displayed



Service menu ^ v

Press key 1.
»Service menu« appears in the display.



Reset Parameters
execute ^ v

Press the Foxkey under v until »Reset parameters« is shown.



.....deleted.....

Press the Foxkey under »execute«.
All user parameters are reset. An acknowledgement message is shown for 5 seconds.

⇒ *Only the user parameters are deleted. All phonebook entries in all memories as well as all greetings, messages and settings for the TAM remain unchanged.*

Important information

Show software version and checksum

You can show the current software version and checksum of your Eurit 33 / 33 plus as follows:



Installation ^ v

Press the menu key until »Installation« is displayed.



Software change ^ v

Press the Foxkey under v until »Software« is displayed.



Version: D 1.00 NDKT2 ^ v

Press the Foxkey under »change«.
The upper display line shows the current software version.



Checksum: execute ^ v

Press the Foxkey under v.
»Checksum« is shown.



Checksum: FAB8 execute ^ v

Press the Foxkey under »Execute«.
The checksum is calculated (the procedure last several seconds) and displayed.

⇒ You need to give the software version and checksum when you contact the service hotline with a problem.

PC dialling option (PC Dialer II)

The Ascom PC Dialer is an add-on for the Eurit 33 / 33 plus that enables Computer Telephone Integration (CTI).

The software delivered with the PC Dialer II contains a TAPI driver and a program for configuring the Eurit 33 / 33 plus and downloading phonebook entries from the PC to the Eurit 33 / 33 plus. Calls are then automatically shown on the screen and stored in the PC.

The TAPI driver allows you to connect certain database programs directly to your Eurit 33 / 33 plus.

Software update

You can use the Ascom PC Dialer II to upgrade the Eurit 33 / 33 plus software.

The firmware required for this procedure is downloadable from the Ascom home page (see back page).

Important information

Technical Data

ISDN

Connection	Basic rate access
Protocol	DSS1 (Euro-ISDN)

Dimensions and weight

D x W x H	205 x 255 x 75 mm
Weight	700 g

Ambient conditions according to DIN IEC 721

Operation	+ 5 ... + 45 °C
Transport	- 25 ... + 70 °C
Storage	- 25 ... + 55 °C

Data storage without power supply

> 10 years (no battery required)

Conformity

The Eurit 33 / 33 plus complies with all relevant EU guidelines and requirements.

Warranty conditions

Ascom offers a guarantee of 24 months from date of purchase for material and production defects in the Eurit 33 / 33 plus. Within the guarantee period, Ascom will rectify free of charge all faults which are caused by faulty material or production errors and reserves the right to correct the fault either by repairing or replacing the defective telephone.

The purchaser must report all faults immediately to the dealer from whom the telephone was purchased. Proof of guarantee must be provided by official confirmation of purchase (receipt or invoice).

Any attempt by the purchaser or a third party to repair the set invalidates the guarantee. Damage caused by incorrect use, operation, storage, acts of God or other external influences are not covered by the guarantee. The guarantee does not cover material or defects which have only a minimal impact on the use or value of the telephone.

Disposal

Please observe local bylaws when disposing of the telephone set.


Important information

Default settings / delivery status


Your Eurit 33 / 33 plus is delivered with the following settings:

Parameter	Status
Autodial (hotline)	Off, no number
Call forwarding with keypad	Off
Incoming EAC	Off
Transfer with disconnect	Off
Call transfer	EURO
Send keypad automatically	On
Headset	Off
Suppress number (CLIR/COLR)	Off
Call waiting	On
Call filter	Off
Call forwarding	Off
Language	country-specific
Display contrast	4 (medium)
Current user	None
Provider	Undefined
Automatic provider choice	Undefined
Redial attempts	10
Interval between 2 redial attempts	60 sec
Ringing volume	4 (medium)
Handset / loudspeaker volume	4 (medium)
Melody	1
Tax factor	country-specific
Taxes	0
Tax unit	country-specific
EAC	None
Speed-dialling	Undefined
MSN	Undefined
User name	Undefined
Park code	1
Phonebook	Empty
Time	12:00
Date	SW-status-specific
TAM	Off
TAM recording quality	High, recording time 10 min
Message length for TAM	60 sec
Greeting for TAM	1
Number of rings until deactivated TAM answers	15
Number of rings until activated TAM answers	4
Listening in	On
Economy function (remote access)	On
Room surveillance (remote access)	Off
PIN code for remote operation	0000

Menu structure



Important information



Index

A		G	
Acoustic signals	10	Greetings	56
Advanced features	23	H	
Automatic callback	29	Handsfree	15
Automatic redial	29, 43	Headset	42
B		Help message	76
Basic settings	38	Hotline	25
C		I	
Call transfer	27	Incoming calls	15
Call acceptance	55	Incoming messages	60
Call filter	49	Info messages	37
Call forwarding	23	K	
Call list (LOG)	13	Keypad information	81
Call transfer on-hook	80	L	
Call waiting	30	Labels	6
Callback, automatic	29	Listening by loudspeaker	16
Caller list	12	Listening in	64
CD	28	Log	13
CLIR Calling Line Identification Restriction	50	M	
Closing message	66	Malicious Call Identification	34
Contents of the package	5	MCID	34
Currency	45	Menu structure	89
D		Menus	10
Default settings	88	Message length	64
Delete parameters	85	MSN	38
Delivery status	88	Multiple Subscriber Number	38
Dialling	12	Mute	16
Dialling from PC	86	O	
Direct access number	74	Operating elements and displays	II
Direct call	25	P	
Display	6, 9	Park code	52
Display signs and symbols	II	Parking	31
Disposal	87	PBX	43
DTMF (Dual Tone Multifrequency)	34	PBX operation	43
E		PC Dialer II	86
EAC	77	Phonebook	17
Emergency mode	7	PIN code	68
Enquiry call	26	Playback	58
F		Provider	46
Forward	28	Provider choice	46
Functions	33		

Index

R

Reactions	20
Recording quality	65
Recording time	65
Redial	11
Reject	15
Remote access functions	70
Reset functions	83
Ring count	63
Room surveillance	73

S

Safety tips	I
Send keypad	35, 82
Send mail (UUS)	36
Set language	41
Setting the contrast	44
Setting the ringing melody	48
Setting the time	40
Setting the volume	48
Setup	5
Software update	86
Software version	86
Special characters	17
Speed-dial key	14
Speed-dialling	32
Status pictograms	9
Subaddresses	35
Suppress call waiting	51
Switching between calls	27
Symbols	II

T

Tax factor	45
Taxes	24
Technical Data	87
Telephone answering machine (TAM)	53
Telephoning	15
Three-party conference	28
Transfer type	79



U

User concept	8
User settings	48
UUS	36

W

Warranty conditions	87
---------------------------	----

Labels



Manufactured in Switzerland by:

Ascom Business Systems Ltd

Eichtal

CH-8634 Hombrechtikon

<http://www.ascom.com>